

20-COMM-H RS-485 HVAC Adapter

Firmware Version 2.xxx



Modbus RTU
Metasys N2
Siemens Building Technologies P1 FLN

User Manual



Important User Information

Solid state equipment has operational characteristics differing from those of electromechanical equipment. *Safety Guidelines for the Application, Installation and Maintenance of Solid State Controls* (Publication SGI-1.1 available from your local Rockwell Automation sales office or online at <http://www.rockwellautomation.com/literature>) describes some important differences between solid state equipment and hard-wired electromechanical devices. Because of this difference, and also because of the wide variety of uses for solid state equipment, all persons responsible for applying this equipment must satisfy themselves that each intended application of this equipment is acceptable.

In no event will Rockwell Automation, Inc. be responsible or liable for indirect or consequential damages resulting from the use or application of this equipment.

The examples and diagrams in this manual are included solely for illustrative purposes. Because of the many variables and requirements associated with any particular installation, Rockwell Automation, Inc. cannot assume responsibility or liability for actual use based on the examples and diagrams.

No patent liability is assumed by Rockwell Automation, Inc. with respect to use of information, circuits, equipment, or software described in this manual.

Reproduction of the contents of this manual, in whole or in part, without written permission of Rockwell Automation, Inc. is prohibited.

Throughout this manual, when necessary we use notes to make you aware of safety considerations.



WARNING: Identifies information about practices or circumstances that can cause an explosion in a hazardous environment, which may lead to personal injury or death, property damage, or economic loss.

Important: Identifies information that is critical for successful application and understanding of the product.



ATTENTION: Identifies information about practices or circumstances that can lead to personal injury or death, property damage, or economic loss. Attentions help you identify a hazard, avoid a hazard, and recognize the consequences.



Shock Hazard labels may be located on or inside the equipment (e.g., drive or motor) to alert people that dangerous voltage may be present.



Burn Hazard labels may be located on or inside the equipment (e.g., drive or motor) to alert people that surfaces may be at dangerous temperatures.

PowerFlex, SMC Flex, DriveExplorer, DriveExecutive, DPI, DriveTools SP, and SCANport are either trademarks or registered trademarks of Rockwell Automation, Inc.

Metasys is a trademark of Johnson Controls, Inc.

Modbus is a trademark of Schneider Automation.

P1 FLN is a trademark of Siemens Building Technologies.

Windows and Microsoft are registered trademarks of Microsoft Corporation.

Summary of Changes

The information below summarizes the changes made to this manual since its last release (March 2004):

Description of Changes	Page
Reformatted document from half size (5.5 x 8.5 in.) to full size (8.5 x 11 in.)	Throughout manual
Added SMC Flex to the list of compatible products, and Metasys N2 is compatible with PowerFlex 700VC drive.	1-2
Added new Adapter Modbus Register Map section.	4-2
Included information about using Modbus RTU mode to access 16-bit and 32-bit parameters.	4-10 and 4-12
Added new Adapter Parameter Direct Access section.	4-13
Added new Metasys N2 Device Identity subsection.	5-1
Added new "Reference Setup Examples" subsection.	5-4
Added tip about configuring Analog Data Integers (ADIs).	5-9
Added Flashing Red/Green MOD status indicator information.	8-3
Added new Parameter 32 - [RTU Param Mode] to select the 16-bit default mode or optional 32-bit mode in which the adapter operates.	B-4

Preface	About This Manual	
	Related Documentation	P-1
	Rockwell Automation Support	P-2
	Conventions Used in This Manual	P-2
Chapter 1	Getting Started	
	Components	1-1
	Features	1-2
	Compatible Products	1-2
	Required Equipment	1-3
	Safety Precautions	1-3
	Quick Start	1-5
	Status Indicators	1-6
Chapter 2	Installing the Adapter	
	Preparing for an Installation	2-1
	Commissioning the Adapter	2-1
	Connecting the Adapter to the Drive	2-3
	Connecting the Adapter to the Network	2-6
	Applying Power	2-7
Chapter 3	Configuring the Adapter	
	Configuration Tools	3-1
	Using the PowerFlex 7-Class HIM	3-2
	Setting the Node Address	3-3
	Setting the Network Data Rate	3-3
	Setting the Network Parity	3-4
	Setting Stop Bits (Modbus RTU only)	3-4
	Setting the I/O Configuration	3-5
	Setting a Network Time-out	3-6
	Setting a Fault Action	3-7
	Resetting the Adapter	3-8
	Viewing the Adapter Status Using Parameters	3-9
	Flash Updating the Adapter	3-10
Chapter 4	Using Modbus RTU	
	Understanding Modbus RTU	4-1
	Adapter Modbus Register Map	4-2
	Using the Modbus RTU Point Map for I/O	4-4
	Accessing Drive Parameters	4-9
	Using Broadcast Messages	4-12
	Adapter Parameter Direct Access	4-13
Chapter 5	Using Metasys N2	
	Understanding Metasys N2	5-1
	Using the Metasys N2 Point Map for I/O	5-3
	Using Metasys Configurable Objects to Access Parameters	5-8

Chapter 6	Using Siemens Building Technologies P1 FLN	
	Understanding Siemens Building Technologies P1 FLN	6-1
	Using the P1 FLN Point Map for I/O	6-5
	Using the P1 FLN Point Map to Access Parameters	6-9
Chapter 7	Using Datalinks with All Protocols	
	Using Datalinks	7-1
	Using Datalinks with Modbus	7-3
	Using Datalinks with Metasys N2	7-4
	Using Datalinks with Siemens P1 FLN	7-5
Chapter 8	Troubleshooting	
	Understanding the Status Indicators	8-1
	PORT Status Indicator	8-2
	MOD Status Indicator	8-2
	NET A Status Indicator	8-3
	NET B Status Indicator	8-3
	Viewing Adapter Diagnostic Items	8-4
	Viewing and Clearing Events.	8-6
Appendix A	Specifications	
	Communications	A-1
	Electrical	A-1
	Mechanical.	A-1
	Environmental	A-1
	Regulatory Compliance	A-2
Appendix B	Adapter Parameters	
	Parameter List	B-1
Appendix C	Logic Command/Status Words	
	PowerFlex 7-Class Drives (except PowerFlex 700S)	C-1
	PowerFlex 700S Drives	C-3
Glossary		
Index		

About This Manual

Topic	Page
Related Documentation	P-1
Rockwell Automation Support	P-2
Conventions Used in This Manual	P-2

Related Documentation

For:	Refer to:	Publication
DriveExplorer™	http://www.ab.com/drives/driveexplorer , and DriveExplorer online help (installed with the software)	—
DriveTools™ SP (includes DriveExecutive™)	http://www.ab.com/drives/drivetools , and DriveExecutive online help (installed with the software)	—
HIM	HIM Quick Reference	20HIM-QR001
PowerFlex® 70/70EC Drive	PowerFlex 70 User Manual PowerFlex 70/700 Reference Manual PowerFlex 70EC/700VC Reference Manual	20A-UM001 PFLEX-RM001 PFLEX-RM004
PowerFlex® 700/700VC Drive PowerFlex® 700 Series B Drive	PowerFlex 700 User Manual PowerFlex 700 Series B User Manual PowerFlex 70/700 Reference Manual PowerFlex 70EC/700VC Reference Manual	20B-UM001 20B-UM002 PFLEX-RM001 PFLEX-RM004
PowerFlex® 700H Drive	PowerFlex 700H Installation Instructions PowerFlex 700H Programming Manual	PFLEX-IN006 20C-PM001
PowerFlex® 700S Drive (Frames 1 through 6)	PowerFlex 700S with Phase I Control User Manual PowerFlex 700S with Phase II Control User Manual PowerFlex 700S Reference Manual	20D-UM001 20D-UM006 PFLEX-RM002
PowerFlex® 700S Drive (Frames 9 and higher)	PowerFlex 700S Installation Instructions PowerFlex 700S with Phase I Control User Manual PowerFlex 700S with Phase II Control User Manual PowerFlex 700S Reference Manual	PFLEX-IN006 20D-UM001 20D-UM006 PFLEX-RM002
PowerFlex® 700L Drive	PowerFlex 700L User Manual	20L-UM001
Modbus RTU Protocol Specification	www.modicon.com/techpubs/TechPubNew	PI_MBUS_300.pdf

You can view or download publications at www.literature.rockwellautomation.com. To order paper copies of technical documentation, contact your local Rockwell Automation distributor or sales representative.

To find your local Rockwell Automation distributor or sales representative, visit www.rockwellautomation.com/locations.

For information such as firmware updates or answers to drive-related questions, go to the Drives Service & Support web site at www.ab.com/support/abdrives and click on the “Downloads” or “Knowledgebase” link.

Rockwell Automation Support

Rockwell Automation, Inc. offers support services worldwide, with over 75 sales/support offices, over 500 authorized distributors, and over 250 authorized systems integrators located through the United States alone. In addition, Rockwell Automation, Inc. representatives are in every major country in the world.

Local Product Support

Contact your local Rockwell Automation, Inc. representative for:

- Sales and order support
- Product technical training
- Warranty support
- Support service agreements

Technical Product Assistance

For technical assistance, please review the information in [Chapter 8, Troubleshooting](#), first. If you still have problems, then access the Allen-Bradley Technical Support web site at www.ab.com/support/abdrives or contact Rockwell Automation, Inc.

Conventions Used in This Manual

The following conventions are used throughout this manual:

- Parameter names are shown in the format **Parameter xx - [*]**. The xx represents the parameter number. The * represents the parameter name—for example **Parameter 01 - [DPI Port]**.
- Menu commands are shown in bold type face and follow the format **Menu > Command**. For example, if you read “Select **File > Open**,” you should click the **File** menu and then click the **Open** command.
- The firmware release is displayed as FRN X.xxx. The “FRN” signifies Firmware Release Number. The “X” is the major release number. The “xxx” is the minor update number.
- This manual provides information about the adapter and using it with PowerFlex 7-Class (Architecture-Class) drives. The adapter can be used with other products that support a DPI™ adapter, such as SMC™ Flex. Refer to the documentation for your product for specific information about how it works with the adapter.


Getting Started

The adapter is a communication option intended for installation into a PowerFlex 7-Class drive. It can also be used with other Allen-Bradley products that support a DPI™ (Drive Peripheral Interface) adapter.

Topic	Page
Components	1-1
Features	1-2
Compatible Products	1-2
Required Equipment	1-3
Safety Precautions	1-3
Quick Start	1-5
Status Indicators	1-6

Components

Figure 1.1 Components of the Adapter



Item	Part	Description
1	Status Indicators	Four LEDs that indicate the status of the DPI, the adapter, and network connection. Refer to Chapter 8, Troubleshooting .
2	DPI Connector	A 20-pin, single-row shrouded male header. An Internal Interface cable is connected to this connector and a connector on the drive.
3	Terminal Block	A 6-screw terminal block connects the adapter to the network.
4	Node Address Switches	Two switches set the node address.
5	Network Selector Switch	Switch selects the network protocol to which the adapter operates.

Features

The adapter features include:

- Typical mounting in a PowerFlex 7-Class drive using captive screws to secure and ground the adapter to the drive.
- Compatibility with various configuration tools to configure the adapter and connected drive. The tools include the PowerFlex HIM on the drive, and drive-configuration software such as DriveExplorer (version 2.01 or higher) or DriveExecutive (version 3.01 or higher).
- Status indicators that report the status of the drive communications, the adapter, and network. They are visible when the drive cover is open or closed.
- Parameter-configurable I/O (Logic Command/Reference and up to four pairs of Datalinks) to meet application requirements.
- User-defined fault actions to determine how the adapter and PowerFlex drive respond to communication disruptions on the network.
- Switches to allow setting a node address before applying power to the drive. Alternatively, you can disable the switches and use a parameter to configure the node address.
- A switch lets you select from the following three network protocols:
 - Modbus™ RTU
 - Metasys™ N2
 - Siemens Building Technologies P1 FLN™
- Available read/write access to parameters, allowing parameter values to be configured and monitored over the network.
- Support for DPI routing, enabling access to any networked PowerFlex 7-Class drive (with 20-COMM-H adapter) using DriveExplorer (version 2.01 or higher) to monitor and configure that drive and its connected peripherals.

Compatible Products

DPI is a second generation peripheral communication interface. The adapter is compatible with Allen-Bradley PowerFlex 7-Class drives and other products that support DPI. At the time of publication, compatible products include:

Network Protocol	Compatible PowerFlex Drives						SMC Flex
	70	700EC	700VC	700H	700S	7000	
Modbus RTU	✓	✓	✓	✓	✓	✓	✓
Metasys N2	✓	✓	✓	✓		✓	
Siemens P1 FLN	✓	✓	✓	✓		✓	

The PowerFlex 70/700 are used for examples in this manual. Refer to a DPI Host product's user manual for additional information.

Required Equipment

Equipment Shipped with the Adapter

When you unpack the adapter, verify that the package includes:

- One adapter
- A 2.54 cm (1 in.) and a 15.24 cm (6 in.) Internal Interface cable (only one cable is needed to connect the adapter to the drive)

User-Supplied Equipment

To install and configure the adapter, you must supply:

- A small flathead screwdriver
- Network-specific cable to connect the adapter to the network. Refer to the network-specific documentation for the cable recommendations and requirements.
- Configuration tool, such as:
 - PowerFlex 7-Class HIM (20-HIM-*)
 - DriveExplorer (version 2.01 or higher)
 - DriveExecutive stand-alone software (version 3.01 or higher) or bundled with the DriveTools SP suite (version 1.01 or higher)
 - Third-party network configuration software
- A PC connection to the network

Safety Precautions

Please read the following safety precautions carefully.



ATTENTION: Risk of injury or death exists. The PowerFlex drive may contain high voltages that can cause injury or death. Remove all power from the PowerFlex drive, and then verify power has been discharged before installing or removing an adapter.



ATTENTION: Risk of injury or equipment damage exists. Only personnel familiar with drive and power products and the associated machinery should plan or implement the installation, start up, configuration, and subsequent maintenance of the product using an adapter. Read and understand this entire manual before proceeding. Failure to comply may result in injury and/or equipment damage.



ATTENTION: Risk of equipment damage exists. The adapter contains ESD (Electrostatic Discharge) sensitive parts that can be damaged if you do not follow ESD control procedures. Static control precautions are required when handling the adapter. If you are unfamiliar with static control procedures, refer to *Guarding Against Electrostatic Damage* (publication 8000-4.5.2).



ATTENTION: Risk of injury or equipment damage exists. If the adapter is transmitting control I/O to the drive, the drive may fault when you reset the adapter. Determine how your drive will respond before resetting an adapter.



ATTENTION: Risk of injury or equipment damage exists. **Parameter 15 - [Comm Flt Action]** lets you determine the action of the adapter and connected drive if communications are disrupted. By default, this parameter faults the drive. You can set this parameter so that the drive continues to run. Precautions should be taken to ensure that the setting of this parameter does not create a risk of injury or equipment damage. When commissioning the drive, verify that your system responds correctly to various situations (for example, a disconnected cable).



ATTENTION: Risk of injury or equipment damage exists. **Parameter 11 - [Network Timeout]** lets you determine how long it will take the adapter to detect network communication losses. By default, this parameter sets the timeout to ten seconds. It can be set so that the duration is shorter, longer, or disabled. Take precautions to ensure that the setting does not create a risk of injury or equipment damage. When commissioning the drive, verify that your system responds correctly to various situations (for example, a disconnected cable).



ATTENTION: Risk of injury or equipment damage exists. DPI or SCANport host products must not be directly connected via 1202 cables. Unpredictable behavior due to timing and other internal procedures can result if two or more hosts are connected in this manner.



ATTENTION: Risk of injury or equipment damage exists. When a system is configured for the first time, there may be unintended or incorrect machine motion. Disconnect the motor from the machine or process during initial system testing.



ATTENTION: Risk of injury or equipment damage exists. The examples in this publication are intended solely for purposes of example. There are many variables and requirements with any application. Rockwell Automation, Inc. does not assume responsibility or liability (to include intellectual property liability) for actual use of the examples shown in this publication.

Quick Start


This section is provided to help experienced users quickly start using the adapter. If you are unsure how to complete a step, refer to the referenced chapter.

Step	Action	Refer to...
1	Review the safety precautions for the adapter.	Throughout This Manual
2	Verify that the PowerFlex drive is properly installed.	Drive User Manual
3	Commission the adapter. Select the network protocol using the adapter Network Selector switch. Set a unique node address using the adapter Node Address switches or set both switches to "0" and configure the node address later using an adapter parameter.	Chapter 2, Installing the Adapter
4	Install the adapter. Verify that the PowerFlex drive and network are not powered. Then, connect the adapter to the network using a network-specific cable and to the drive using the Internal Interface cable. Use the captive screws to secure and ground the adapter to the drive.	Chapter 2, Installing the Adapter
5	Apply power to the adapter. A. The adapter receives power from the drive. Verify that the adapter and network are installed correctly and then turn on the network and apply power to the drive. The status indicators should be green. If they flash red, there is a problem. Refer to Chapter 8, Troubleshooting . B. Configure/verify key drive parameters.	Chapter 2, Installing the Adapter
6	Configure the adapter for your application. Set adapter parameters for the following functions as required by your application: <ul style="list-style-type: none"> • Node address, data rate, and parity • I/O configuration • Fault actions 	Chapter 3, Configuring the Adapter
7	Set up the master device to communicate with the adapter. Use a network tool to configure the master device on the network.	Instruction manual for your network tool

Status Indicators

The adapter uses four status indicators to report its operating status. They can be viewed on the adapter or through the drive cover ([Figure 1.2](#)).

Figure 1.2 Status Indicators (location on drive may vary)



Item	Name
①	PORT
②	MOD
③	NET A
④	NET B

After installing the adapter and applying power to the drive, refer to [Start-Up Status Indications on page 2-7](#) for possible start-up status indications and their descriptions.

Installing the Adapter

This chapter provides instructions for installing the adapter in a PowerFlex 7-Class drive.

Topic	Page
Preparing for an Installation	2-1
Commissioning the Adapter	2-1
Connecting the Adapter to the Drive	2-3
Connecting the Adapter to the Network	2-6
Applying Power	2-7

Preparing for an Installation Before installing the adapter, verify that you have all required equipment. Refer to [Required Equipment on page 1-3](#).

Commissioning the Adapter To commission the adapter, you must set a unique node address and select a network protocol.

Important: New settings are recognized only when power is applied to the adapter or it is reset. If you change a switch setting, cycle power or reset the adapter to activate the changes.




ATTENTION: Risk of equipment damage exists. The adapter contains ESD (Electrostatic Discharge) sensitive parts that can be damaged if you do not follow ESD control procedures. Static control precautions are required when handling the adapter. If you are unfamiliar with static control procedures, refer to *Guarding Against Electrostatic Damage* (publication 8000-4.5.2).

Important: To guard against device malfunction, it is recommended wear a grounding wrist strap when installing the adapter.

1. Set the adapter’s node address by rotating the node address switches to the desired value for each digit.

Important: Each node on the network must have a unique address.


Figure 2.1 Setting the Node Address



Setting	Description
01 – 99	Node address used by the adapter.
00 (Default)	If network protocols are capable of handling a node address of 0 or node addresses higher than 99, these addresses can be configured by setting the switches to 00 and then setting Parameter 03 - [Net Addr Cfg] to the desired network node address.

2. Set the network protocol switch.

Figure 2.2 Setting the Network Protocol



Setting	Description
RTU (Default)	Modbus RTU
N2	Metasys N2
P1	Siemens Building Technologies P1 FLN

The switch settings can be verified using a PowerFlex HIM, DriveExplorer software, or DriveExecutive software, and viewing Diagnostic Device Item numbers 40-42 ([page 8-5](#)).

Connecting the Adapter to the Drive




ATTENTION: Risk of injury or death exists. The PowerFlex drive may contain high voltages that can cause injury or death. Remove power from the drive, and then verify power has been discharged before installing or removing the adapter.

1. Remove power from the drive and network.
2. Use static control precautions.
3. Remove the drive cover or open the drive door.
4. Connect the Internal Interface cable to the DPI port on the drive and then to the DPI connector on the adapter (see [Figure 2.3](#)).
5. Secure and ground the adapter to the drive (see [Figure 2.4](#)) by doing the following:
 - On a PowerFlex 70 drive, fold the Internal Interface cable behind the adapter and mount the adapter on the drive using the four captive screws.
 - On a PowerFlex 700, PowerFlex 700H or PowerFlex 700S drive, mount the adapter on the drive using the four captive screws.


Important: Tighten all screws to properly ground the adapter.
Recommended torque is 0.9 N•m (8.0 lb•in).

Figure 2.3 DPI Ports and Internal Interface Cables




Item	Description
❶	15.24 cm (6 in.) Internal Interface cable
❷	DPI Connector
❸	Ethernet cable
❹	2.54 cm (1 in.) Internal Interface cable

Figure 2.4 Mounting and Grounding the Adapter




0.9 N•m
(8.0 lb•in)
4 Places




Internal Interface Cable
folded behind the adapter
and in front of the drive.


PowerFlex 70 - All Frame Sizes
(Adapter mounts in drive.)



0.9 N•m
(8.0 lb•in)
4 Places




Ground Tab Detail



Verify metal ground tab is bent 90°
and is under the adapter before
tightening screw. After tightening
the screw, verify continuity exists
between the head of the screw
and drive ground.


PowerFlex 700 Frames 0 and 1
PowerFlex 700S Frames 0 and 1
(Adapter mounts on door.)

PowerFlex 700 Frames 2 and Larger
PowerFlex 700S Frames 2 through 6
(Adapter mounts in drive.)



0.9 N•m
(8.0 lb•in)
4 Places

Ground Tab Detail



Verify metal ground tab is bent 90°
and is under the adapter before
tightening screw. After tightening
the screw, verify continuity exists
between the head of the screw
and drive ground.

PowerFlex 700H Frames 9 and Larger
PowerFlex 700S Frames 9 and Larger
(Adapter mounts behind HIM panel.)


Connecting the Adapter to the Network



ATTENTION: Risk of injury or death exists. The PowerFlex drive may contain high voltages that can cause injury or death. Remove power from the drive, and then verify power has been discharged before installing or removing the adapter.

1. Remove power from the network and drive.
2. Use static control precautions.
3. Connect an RS-485 cable to the network, and route it through the bottom of the PowerFlex drive (Figure 2.4).
4. Connect a six-pin linear plug to the RS-485 cable. (See Figure 2.5 for the terminal definitions.)

Figure 2.5 Typical Network Connections



Terminal	Signal	Function
TERM	Termination ⁽¹⁾	Signal RC Termination
A	Signal A	TxRxD-
B	Signal B	TxRxD+
COM	Common	Signal Common
SHIELD	Shield	Shield RC Termination
GND	Ground ⁽²⁾	Shield GND Termination

⁽¹⁾ Jumper terminals TERM and A on the adapter at end of the RS-485 network. This enables a built-in RC termination network on the adapter.

⁽²⁾ The shield must be grounded at a single point on the network (jumper terminals SHIELD and GND).

A 3-wire network using Belden 3106A cable or equivalent is recommended for Modbus RTU applications and shown in Figure 2.3 above. A 2-wire network using Belden 3105A cable or equivalent (COM terminal is not connected) can also be used for most applications. However, a 3-wire network is more robust in noisy environments.

For Metasys N2 or Siemens P1 FLN applications, refer to published guidelines from Johnson Controls or Siemens Building Technologies respectively.

Applying Power



ATTENTION: Risk of equipment damage, injury, or death exists. Unpredictable operation may occur if you fail to verify that parameter settings are compatible with your application. Verify that settings are compatible with your application before applying power to the drive.

Install the drive cover or close the drive door, and apply power to the drive. The adapter receives its power from the connected drive. When you apply power to the adapter for the first time, its topmost “PORT” status indicator should be steady green after an initialization. If it is red, there is a problem. Refer to [Chapter 8, Troubleshooting](#).

Start-Up Status Indications

Status indicators for the drive and communications adapter can be viewed on the front of the drive ([Figure 2.6](#)) after power has been applied. Possible start-up status indications are shown in [Table 2.A](#).

Figure 2.6 Drive and Adapter Status Indicators (location on drive may vary)




Table 2.A Drive and Adapter Start-Up Status Indications

Item	Name	Color	State	Description
Drive STS Indicator				
①	STS (Status)	Green	Flashing	Drive ready but not running, and no faults are present.
			Steady	Drive running, no faults are present.
		Yellow	Flashing, Drive Stopped	An inhibit condition exists – the drive cannot be started. Check drive Parameter 214 - [Start Inhibits].
			Flashing, Drive Running	An intermittent type 1 alarm condition is occurring. Check drive Parameter 211 - [Drive Alarm 1].
			Steady, Drive Running	A continuous type 1 alarm condition exists. Check drive Parameter 211 - [Drive Alarm 1].
		Red	Flashing	A fault has occurred.
Steady	A non-resettable fault has occurred.			

Item	Name	Color	State	Description
Adapter Status Indicators				
②	PORT	Green	Flashing	Normal Operation. The adapter is establishing an I/O connection to the drive. It will turn solid green or red.
			Steady	Normal Operation. The adapter is properly connected and communicating with the drive
	MOD	Green	Flashing	Normal Operation. The adapter is operating but is not transferring I/O data.
			Steady	Normal Operation. The adapter is operating and transferring I/O data.
	NET A	Green	Flashing	Normal Operation. The adapter is properly connected but does not have an I/O connection.
			Steady	Normal Operation. The adapter is properly connected and communicating on the network.
	NET B	Green	Off	Normal Operation. The adapter is properly connected but is idle.
			Flashing	Normal Operation. The adapter is properly connected and transmitting data packets on the network.

Configuring/Verifying Key Drive Parameters

The PowerFlex 7-Class drive can be separately configured for the control and Reference functions in various combinations. For example, you could set the drive to have its control come from a peripheral or terminal block with the Reference coming from the network. Or you could set the drive to have its control come from the network with the Reference coming from another peripheral or terminal block. Or you could set the drive to have both its control and Reference come from the network.

The following steps in this section assume that the drive will receive the Logic Command and Reference from the network.

1. Use drive Parameter 090 - [Speed Ref A Sel] to set the drive speed Reference to “22” (DPI Port 5).
2. If digital inputs are not used, change drive Parameters 361 - [Dig In1 Sel] through 366 - [Dig In6 Sel] to “0” (Not Used).
3. Verify that drive Parameter 213 - [Speed Ref Source] is reporting that the source of the Reference to the drive is “22” (DPI Port 5). This ensures that any Reference commanded from the network can be monitored by using drive Parameter 002 - [Commanded Speed]. If a problem occurs, this verification step provides the diagnostic capability to determine whether the drive/adapter or the network is the cause.

Configuring the Adapter

This chapter provides instructions and information for setting the parameters in the adapter.

Topic	Page
Configuration Tools	3-1
Using the PowerFlex 7-Class HIM	3-2
Setting the Node Address	3-3
Setting the Network Data Rate	3-3
Setting the Network Parity	3-4
Setting Stop Bits (Modbus RTU only)	3-4
Setting the I/O Configuration	3-5
Setting a Network Time-out	3-6
Setting a Fault Action	3-7
Resetting the Adapter	3-8
Viewing the Adapter Status Using Parameters	3-9
Flash Updating the Adapter	3-10

For a list of parameters, refer to [Appendix B, Adapter Parameters](#). For definitions of terms in this chapter, refer to the [Glossary](#).

Configuration Tools

The adapter stores parameters and other information in its own non-volatile memory. You must, therefore, access the adapter to view and edit its parameters. The following tools can be used to access the adapter parameters:

Tool	Refer to...
PowerFlex HIM	page 3-2
DriveExplorer Software (version 2.01 or higher)	http://www.ab.com/drives/driveexplorer , or DriveExplorer online help (installed with the software)
DriveExecutive Software (version 3.01 or higher)	http://www.ab.com/drives/drivetools , or DriveExecutive online help (installed with the software)




Using the PowerFlex 7-Class HIM

If your drive has either an LED or LCD HIM (Human Interface Module), it can be used to access parameters in the adapter as shown below. It is recommended that you read through the steps for your HIM before performing the sequence. For additional information, refer to your PowerFlex Drive User Manual or the HIM Quick Reference card.

Using an LED HIM

Step	Key(s)	Example Screens
1. Press ALT and then Sel (Device) to display the Device Screen.	 	
2. Press the Up Arrow or Down Arrow to scroll to the adapter. Letters represent files in the drive, and numbers represent ports. The adapter is usually connected to port 5.	 or 	
3. Press the Enter key to enter your selection. A parameter database is constructed, and then the first parameter is displayed.		
4. Edit the parameters using the same techniques that you use to edit drive parameters.		

Using an LCD HIM

Step	Key(s)	Example Screens
1. In the main menu, press the Up Arrow or Down Arrow to scroll to Device Select .	 or 	
2. Press Enter to enter your selection.		
3. Press the Up Arrow or Down Arrow to scroll to the adapter (20-COMM-H).	 or 	
4. Press Enter to select the adapter. A parameter database is constructed, and then the main menu for the adapter is displayed.		
5. Edit the parameters using the same techniques that you use to edit drive parameters.		

NOTE: LCD HIM screens are shown throughout this chapter for example configuration procedures.

Setting the Node Address

If the Node Address switches on the adapter are set to “00,” the value of **Parameter 03 - [Net Addr Cfg]** determines the node address.

1. Set the value of **Parameter 03 - [Net Addr Cfg]** to a unique node address.

Figure 3.1 Example Net Addr Cfg 1 Screen

Port 5 Device 20-COMM-H	Default = 1
Parameter #: 03 Net Addr Cfg	
1	0 <> 247

2. Reset the adapter (see [Resetting the Adapter on page 3-8](#)). The actual node address is then displayed by **Parameter 04 - [Net Addr Act]**.

Setting the Network Data Rate

The data rate at which the adapter operates varies based on the type of network and your network configuration. Refer to the following table.

Network	Possible Data Rates
Modbus RTU	4800, 9600, 19200, 38400
Metasys N2	9600
Siemens Building Technologies P1 FLN	4800, 9600

1. Set the value of **Parameter 05 - [Net Rate Cfg]** to the data rate at which your network is operating.

Figure 3.2 Example Net Rate Cfg Screen

Port 5 Device 20-COMM-H	Value	Baud
Parameter #: 05 Net Rate Cfg	0	4800
1	1	9600 (default)
9600	2	19200
	3	38400

2. Reset the adapter (see [Resetting the Adapter on page 3-8](#)). The actual data rate is then displayed by **Parameter 06 - [Net Rate Act]**.

Setting the Network Parity

The parity that the adapter uses to verify data integrity varies based on the type of network and your network configuration. Refer to the following table.

Network	Possible Types of Parity
Modbus RTU	None, Even, or Odd
Metasys N2	None
Siemens Building Technologies P1 FLN	None

1. Set the value of **Parameter 07 - [Net Parity Cfg]** to the type of parity that is used on the network.

Figure 3.3 Example Network Parity Screen

Port 5 Device 20-COMM-H
Parameter #: 07 Net Parity Cfg 0 None

Value	Type of Parity
0	None (default)
1	Odd
2	Even

2. Reset the adapter (see [Resetting the Adapter on page 3-8](#)). The actual network parity is then displayed by **Parameter 08 - [Net Parity Act]**.

Setting Stop Bits (Modbus RTU only)

Parameter 30 - [Stop Bits Cfg] enables you to set 1 or 2 stop bits for the Modbus RTU network protocol. When the adapter rotary switch is set to “N2” or “P1,” the Stop Bits Cfg value is ignored and does not transfer to read-only **Parameter 09 - [Stop Bits Act]** on power-up or reset (N2 and P1 are fixed at 1 stop bit).

1. Set the value of **Parameter 30 - [Stop Bits Cfg]**.

Figure 3.4 Example Stop Bits Screen

Port 5 Device 20-COMM-H
Parameter #: 30 Stop Bits Cfg 0 1-bit

Value	Type of Stop Bit
0	1-bit (default)
1	2-bits

2. Reset the adapter (see [Resetting the Adapter on page 3-8](#)). The actual stop bits is then displayed by **Parameter 09 - [Stop Bits Act]**.

Setting the I/O Configuration

The I/O configuration determines the data that is sent to and from the drive. Logic Command/Status, Reference/Feedback, and Datalinks may be enabled or disabled. A “1” enables the I/O. A “0” disables the I/O.

1. Set the bits in **Parameter 16 - [DPI I/O Cfg]**.

Figure 3.5 Example DPI I/O Cfg Screen

Port 5 Device 20-COMM-H		Bit	Description
Parameter #: 16 DPI I/O Cfg x x x x x x x x x x 0 0 0 0 1 Cmd/Ref b00		0	Logic Command/Reference (Default)
		1	Datalink A
		2	Datalink B
		3	Datalink C (not used with Metasys N2)
		4	Datalink D (not used with Metasys N2)
		5 - 15	Not Used

Bit 0 is the right-most bit. In [Figure 3.5](#), it is highlighted and equals “1.”

2. If Logic Command/Reference is enabled, configure the parameters in the drive to accept the Logic Command and Reference from the adapter. For example, set Parameter 90 - [Speed Ref A Sel] in a PowerFlex 70 or 700 drive to “22” (DPI Port 5) so that the drive uses the Reference from the adapter. Also, verify that the mask parameters (for example, Parameter 276 - [Logic Mask]) in the drive are configured to receive the desired logic from the adapter. Refer to the documentation for your drive for details.
3. If you enabled one or more Datalinks, configure parameters in the drive to determine the source and destination of data in the Datalink(s). For example, configure the Datalinks in PowerFlex 70 and 700 drives by setting Parameters 300 - [Data In A1] to 317 - [Data Out D2]. Also, ensure that this adapter is the only adapter using the enabled Datalink(s).
4. Reset the adapter (see [Resetting the Adapter on page 3-8](#)).

The adapter is ready to send and receive I/O. The following chapters provide information about basic data transfer for each type of protocol.

Network	Refer to...
Modbus RTU	Chapter 4, Using Modbus RTU
Metasys N2	Chapter 5, Using Metasys N2
Siemens Building Technologies P1 FLN	Chapter 6, Using Siemens Building Technologies P1 FLN

For details about using Datalinks for all types of networks, refer to [Chapter 7, Using Datalinks with All Protocols](#).

Setting a Network Time-out

The network timeout sets an interval within which the adapter must communicate with its master. If this time is exceeded, the adapter determines a loss of network communications has occurred and responds with the action specified in **Parameter 15 - [Comm Flt Action]**.


By default, the timeout is set to ten (10) seconds. You can increase or decrease this value. Alternatively, you can set the value to zero (0) so that the adapter does not detect communication losses.



ATTENTION: Risk of injury or equipment damage exists. **Parameter 11 - [Network Timeout]** lets you determine how long it will take your adapter to detect network communication losses. By default, this parameter sets the timeout to ten (10) seconds. You can set it so that the duration is shorter, longer, or disabled. Take precautions to ensure that the setting does not create a risk of injury or equipment damage. When commissioning the drive, verify that your system responds correctly to various situations (for example, a disconnected cable).

Set the network timeout in **Parameter 11 - [Network Timeout]**.

Figure 3.6 Example Network Timeout Screen



Changes to this parameter take effect immediately. A reset is not required.

Setting a Fault Action

By default, when I/O communications are disrupted (for example, a cable is disconnected), the drive responds by faulting if it is using I/O from the network. You can configure a different response to disrupted I/O communication using **Parameter 15 - [Comm Flt Action]**.



ATTENTION: Risk of injury or equipment damage exists. **Parameter 15 - [Comm Flt Action]** lets you determine the action of the adapter and connected drive if I/O communications are disrupted. By default, this parameter faults the drive. You can set this parameter so that the drive continues to run. Precautions should be taken to ensure that the setting of this parameter does not create a risk of injury or equipment damage. When commissioning the drive, verify that your system responds correctly to various situations (for example, a disconnected cable).

Changing the Fault Action

Set the value of **Parameter 15 - [Comm Flt Action]** to the desired response:

Value	Action	Description
0	Fault	The drive is faulted and stopped. (Default)
1	Stop	The drive is stopped, but not faulted.
2	Zero Data	The drive is sent 0 for output data. (The command word and Reference are set to zero.) This does not command a stop.
3	Hold Last	The drive continues in its present state.
4	Send Flt Cfg	The drive is sent the data that you set in the fault configuration parameters (Parameters 18 - [Flt Cfg Logic] through 27 - [Flt Cfg D2 In]).

Figure 3.7 Example Fault Action Screen

Port 5 Device 20-COMM-H
Parameter #: 15 Comm Flt Action 0
Fault

Changes to this parameter takes effect immediately. A reset is not required.

Setting the Fault Configuration Parameters

If you set **Parameter 15 - [Comm Flt Action]** to “Send Flt Cfg,” the values in the following parameters are sent to the drive after an I/O communications fault occurs. You must set these parameters to values required by your application.

Parameter	Name	Description
25	Flt Cfg Logic	A 16-bit value sent to the drive for Logic Command.
26	Flt Cfg Ref	A 32-bit value (0 – 4294967295) sent to the drive as a Reference or Datalink.
27 – 34	Flt Cfg x1 In or Flt Cfg x2 In	Important: If the drive uses a 16-bit Reference or 16-bit Datalinks, the most significant word of the value must be set to zero (0) or a fault will occur.

Changes to these parameters take effect immediately. A reset is not required.

Resetting the Adapter

Changes to switch settings and some adapter parameters require that you reset the adapter before the new settings take effect. You can reset the adapter by cycling power to the drive or by using **Parameter 14 - [Reset Module]**.



ATTENTION: Risk of injury or equipment damage exists. If the adapter is transmitting control I/O to the drive, the drive may fault when you reset the adapter. Determine how your drive will respond before resetting a connected adapter.

Set **Parameter 14 - [Reset Module]** to “1” (Reset Module).

Figure 3.8 Example Reset Module Screen

Port 5 Device	
20-COMM-H	
Parameter #: 14	
Reset Module	
1	
Reset Module	

Value	Description
0	Ready (Default)
1	Reset Module
2	Set Defaults

When you enter “1” (Reset Module), the adapter will be immediately reset. When you enter “2” (Set Defaults), the adapter will set all adapter parameters to their factory-default values. After performing a Set Defaults, enter “1” (Reset Module) so that the new values take effect. The value of this parameter will be restored to “0” (Ready) after the adapter is reset.

Viewing the Adapter Status Using Parameters

The following parameters provide information about the status of the adapter. You can view these parameters at any time.

Parameter	Description																											
04 - [Net Add Act]	Displays the actual network address of the adapter.																											
06 - [Net Rate Act]	Displays the network data rate actually used by the adapter. Only valid values for the specified network are displayed.																											
08 - [Net Parity Act]	Displays the actual network parity used by the adapter. Only valid values for the specified network are displayed.																											
09 - [Stop Bits Act]	<p>Displays the actual number of stop bits used by the selected protocol.</p> <p>This value is network-dependent:</p> <ul style="list-style-type: none"> • ModBus RTU Protocol – The number of stop bits used depends on the value set by Parameter 30 - [Stop Bits Cfg]. If the value is “0,” the adapter uses 1 stop bit; otherwise, it uses 2 stop bits. • Metasys N2 Protocol – Uses only 1 bit, so the adapter shows only this value. • Siemens Building Technologies P1 FLN Protocol – Uses only 1 bit, so the adapter shows only this value. 																											
10 - [Net Chksum Type]	<p>Displays the type of checksum used by the selected protocol. The values are as follows:</p> <ul style="list-style-type: none"> • CRC16 (0) is Cyclic Redundancy Check with 0 as a seed value. The Siemens Building Technologies P1 FLN protocol uses this checksum. • RLC is Run Length Checksum. The Metasys N2 protocol uses this checksum. <p>CRC16 (-1) is Cyclic Redundancy Check with -1 as a seed value. The Modbus RTU protocol uses this checksum.</p>																											
17 - [DPI I/O Act]	<p>Displays the Reference/Feedback and Datalinks used by the adapter. This value is the same as Parameter 16 - [DPI I/O Cfg] unless the parameter was changed and the adapter was not reset.</p> <table border="1" style="margin-left: auto; margin-right: auto;"> <thead> <tr> <th>Bit Definition</th> <th>Not Used</th> <th>Not Used</th> <th>Not Used</th> <th>Datalink D</th> <th>Datalink C</th> <th>Datalink B</th> <th>Datalink A</th> <th>Cmd/Ref</th> </tr> </thead> <tbody> <tr> <td>Default</td> <td>x</td> <td>x</td> <td>x</td> <td>0</td> <td>0</td> <td>0</td> <td>0</td> <td>1</td> </tr> <tr> <td>Bit</td> <td>7</td> <td>6</td> <td>5</td> <td>4</td> <td>3</td> <td>2</td> <td>1</td> <td>0</td> </tr> </tbody> </table> <p style="text-align: right;">0 = I/O disabled 1 = I/O enabled</p>	Bit Definition	Not Used	Not Used	Not Used	Datalink D	Datalink C	Datalink B	Datalink A	Cmd/Ref	Default	x	x	x	0	0	0	0	1	Bit	7	6	5	4	3	2	1	0
Bit Definition	Not Used	Not Used	Not Used	Datalink D	Datalink C	Datalink B	Datalink A	Cmd/Ref																				
Default	x	x	x	0	0	0	0	1																				
Bit	7	6	5	4	3	2	1	0																				

Flash Updating the Adapter

The adapter can be flash updated over the network or serially through a direct connection from a computer to the drive using a 1203-USB or 1203-SSS serial converter.

When flashing over the network, you can use the Allen-Bradley software tool ControlFLASH, the built-in flash capability of DriveExplorer Lite or Full, or the built-in flash capability of DriveExecutive.

When flashing through a direct serial connection from a computer to a drive, you can use the same Allen-Bradley software tools described above, or you can use HyperTerminal set to the X-modem protocol.

To obtain a flash update for this adapter, go to <http://www.ab.com/support/abdrives/webupdate>. This site contains all firmware update files and associated Release Notes that describe firmware update enhancements/anomalies, how to determine the existing firmware version, and how to flash update using DriveExplorer, DriveExecutive, ControlFLASH or HyperTerminal.

Using Modbus RTU

This chapter provides information about controlling a PowerFlex 7-Class drive, setting its Reference, and accessing its parameters through configurable objects when the Modbus RTU network protocol is selected.

Topic	Page
Understanding Modbus RTU	4-1
Using the Modbus RTU Point Map for I/O	4-4
Accessing Drive Parameters	4-9
Using Broadcast Messages	4-12



TIP: Datalinks can also be used for accessing parameters. For information about using Datalinks, refer to [Chapter 7, Using Datalinks with All Protocols](#).

Understanding Modbus RTU

The Modbus RTU protocol is a messaging structure used to establish master-slave communication between intelligent devices. The protocol defines the format of the messages.

Messages from a master to a slave contain the address of the slave, a function code defining the requested action, any data to be sent, and an error-checking field. Messages from a slave to a master contain fields confirming the action taken, any data to be returned, and an error-checking field. If an error occurred in the receipt of the message or if the slave is unable to perform the requested action, the slave will construct an error message and send it as its response.

Modbus RTU can access a single address or multiple addresses simultaneously, either reading or writing single-bit values or 16-bit values.

Modbus RTU Data Formats

Modbus data types are 1-bit and 16-bit values. Refer to [Table 4.A](#).

Table 4.A Modbus RTU Data Formats

Modbus Type	Description	Reference
Coil Status	1-bit Discrete Output	0x
Input Status	1-bit Discrete Input	1x
Holding Register	16-bit Output Register	4x
Input Register	16-bit Input Register	3x

Supported Modbus RTU Commands

The adapter supports the Modbus RTU commands listed in [Table 4.B](#).

Table 4.B Modbus RTU Commands Supported by RS-485 Adapter

Function Code	Description
01	Read Coil Status
02	Read Input Status
03	Read Holding Registers
04	Read Input Registers
05	Force Single Coil
06	Write Single Register
08	Diagnostics Subfunction 00 Only - Return Query Data (loop back)
16	Write Multiple Registers
23	Read/Write 4x Registers

Data Addresses in Modbus Messages

All data addresses in Modbus messages are referenced to zero. That is, the first occurrence of a data item is addressed as item number zero. Therefore, when you create a message, you must address it to one less than the Modbus address in the manual. The following are examples:

- Logic Command is Holding Register address 4x0001 in [Table 4.F on page 4-7](#), so you address it as register “0000” in the data address field of the message.
- Feedback Hi is Input Register address 3x0003 in [Table 4.H on page 4-8](#), so you address it as register “0002” in the data address field of the message.
- Start is Coil address 0x0002 in [Table 4.E on page 4-6](#), so you address it as coil “0001” in the data address field of the message.
- At Speed is Input address 1x0009 in [Table 4.G on page 4-7](#), so you address it as input “0008” in the data address field of the message.

Adapter Modbus Register Map

[Table 4.C](#) provides an overview of the Modbus register addresses and their related functions.

Table 4.C Adapter Modbus Register Map

Modbus Register	Function
Write Product Command Word Bits	
0x0001	Stop
0x0002	Start
0x0003	Jog
0x0004	Clear Faults
0x0005	Direction
0x0006	
0x0007	Local Control
0x0008	MOP Increment

Table 4.C Adapter Modbus Register Map (Continued)

Modbus Register	Function
0x0009	Accel Rate
0x0010	
0x0011	Decel Rate
0x0012	
0x0013	Reference Select
0x0014	
0x0015	
0x0016	MOP Decrement
Read Product Status Word Bits	
1x0001	Ready
1x0002	Active
1x0003	Command Direction
1x0004	Actual Direction
1x0005	Accel
1x0006	Decel
1x0007	Alarm
1x0008	Fault
1x0009	At Speed
1x0010	Local Control
1x0011	
1x0012	
1x0013	Reference
1x0014	
1x0015	
1x0016	
Read Various Input Registers	
3x0001	Product Status Word
3x0002	Feedback Lo (Bits 0...15 of 32-bit Feedback)
3x0003	Feedback Hi (Bits 16...31 of 32-bit Feedback or whole 16-bit Feedback)
3x0004	Read USER IN 1
3x0005	Read USER IN 2
3x0006	Read USER IN 3
3x0007	Read USER IN 4
3x0008	Read USER IN 5
3x0009	Read USER IN 6
3x0010	Read USER IN 7
3x0011	Read USER IN 8
3x0012	Read Datalink A1 Out
3x0013	
3x0014	Read Datalink A2 Out
3x0015	
3x0016	Read Datalink B1 Out
3x0017	
3x0018	Read Datalink B2 Out
3x0019	
3x0020	Read Datalink C1 Out
3x0021	
3x0022	Read Datalink C2 Out
3x0023	
3x0024	Read Datalink D1 Out
3x0025	
3x0026	Read Datalink D2 Out
3x0027	

Table 4.C Adapter Modbus Register Map (Continued)

Modbus Register	Function
Write Various Holding Registers	
4x0001	Product Logic Command
4x0002	Reference Lo (Bits 0...15 of 32-bit Reference)
4x0003	Reference Hi (Bits 16...31 of 32-bit Reference or whole 16-bit Reference)
4x0004	Parameter # for USER IN1
4x0005	Parameter # for USER IN2
4x0006	Parameter # for USER IN3
4x0007	Parameter # for USER IN4
4x0008	Parameter # for USER IN5
4x0009	Parameter # for USER IN6
4x0010	Parameter # for USER IN7
4x0011	Parameter # for USER IN8
4x0012	Write USER OUT1
4x0013	Write USER OUT2
4x0014	Write USER OUT3
4x0015	Parameter # for USER OUT1
4x0016	Parameter # for USER OUT2
4x0017	Parameter # for USER OUT3
4x0018	Write Datalink A1 In
4x0019	
4x0020	Write Datalink A2 In
4x0021	
4x0022	Write Datalink B1 In
4x0023	
4x0024	Write Datalink B2 In
4x0025	
4x0026	Write Datalink C1 In
4x0027	
4x0028	Write Datalink C2 In
4x0029	
4x0030	Write Datalink D1 In
4x0031	
4x0032	Write Datalink D2 In
4x0033	
Direct Parameter Access	
4x0100 + param #	20-COMM-H Parameter Direct Access (with adapter in 16-bit mode)
4x0100 + (param # x 2)	20-COMM-H Parameter Direct Access (with adapter in 32-bit mode)
4x1000 + param #	Drive Parameter Direct Access (with adapter in 16-bit mode)
4x1000 + (param # x 2)	Drive Parameter Direct Access (with adapter in 32-bit mode)

Using the Modbus RTU Point Map for I/O

On Modbus, data transfers are used to transfer the I/O data that controls the drive and sets its Reference. Note that *output I/O* is data that the master device sends and the adapter receives. *Input I/O* is status data that the adapter sends and the master device receives.

Important: In order for the drive to use the I/O and Reference from the Modbus RTU network, you must set parameters in it and the adapter to receive the I/O and Reference. For details, refer to [Setting the I/O Configuration on page 3-5](#).

Setting the Logic Command and Reference



ATTENTION: Select and use **either** the “Product Logic Command Discrete Outputs (0x000x)” or the “Product Logic Command Register Output (4x0001)” as a control method, but **not both**. Conflicts caused from using both methods can result in dangerous operation. Failure to observe this caution could cause bodily injury and/or damage to equipment.

On Modbus RTU, there are two ways to set the logic command: discrete outputs ([Table 4.E on page 4-6](#)) and register outputs ([Table 4.F on page 4-7](#)).

- When you need to set only one bit in the logic command word, you can use a discrete output. For example, to stop a PowerFlex 70/700 drive (bit 0), you can use a discrete output (Modbus Address 0x0001).
- When you need to set multi-bit fields in the logic status word or to set the entire logic status word, you must use the register output to maintain data integrity. For example, to set the direction of a PowerFlex 70/700 drive (bits 4 and 5), you must use a register output (Modbus Address 4x0001).

A 16-bit product logic word is buffered in the adapter, holding the last logic command sent to the drive regardless of whether it was sent through the discrete outputs or through the product logic command register output. When a bit is updated through the discrete outputs or the register output, a new logic command is generated and sent to the drive.

To set the Reference, you must use a register output (Modbus Address 4x0002 and/or 4x0003 in [Table 4.F on page 4-7](#)). Remember that the Reference value is a scaled value; it is not an engineering value. For example, in PowerFlex 70/700 drives, the reference is scaled based on the value of **Parameter 55 - [Maximum Freq]**, but the commanded maximum speed can never exceed the value of **Parameter 82 - [Maximum Speed]**. [Table 4.D](#) shows example References and their results on a PowerFlex 70/700 drive that has its **Parameters 55 - [Maximum Freq]** set to 130 Hz and **82 - [Maximum Speed]** set to 60 Hz.

Table 4.D Example Speed Reference and Feedback for a PowerFlex 70/700

Reference Value	Scale		Output Speed	Feedback Value
	Percent	Value		
32767 ⁽¹⁾	100%	130 Hz	60 Hz ⁽²⁾	15123 ⁽³⁾
16384	50%	65 Hz	60 Hz ⁽²⁾	15123 ⁽³⁾
8192	25%	32.5 Hz	32.5 Hz	8192
0	0%	0 Hz	0 Hz	0

⁽¹⁾ A value of 32767 is equivalent to 100%. The effects of values greater than 32767 depend on whether the DPI product uses a bipolar or unipolar direction mode. Refer to the documentation for your DPI product.

⁽²⁾ The drive runs at 60 Hz instead of 130 Hz or 65 Hz because Parameter 82 - [Maximum Speed] sets 60 Hz as the maximum speed.

⁽³⁾ The Feedback value is also scaled based on the value of Parameter 55 - [Maximum Freq]. For example, $60/130 = 0.46$ so $32767 \times 0.46 = 15123$.

[Table 4.E](#) shows that there are 16 discrete points to represent the command word bit by bit. These points can be used only for writing single-bit commands.

Table 4.E Logic Command: Discrete Outputs (to Drive from Controller)

Modbus Address	Logic Command Bit	PowerFlex 70/700 Example	
		Description	Values
0x0001	0	Stop	0 = Not Stop 1 = Stop
0x0002	1	Start ⁽¹⁾ ⁽²⁾	0 = Not Start 1 = Start
0x0003	2	Jog	0 = Not Jog 1 = Jog
0x0004	3	Clear Faults ⁽²⁾	0 = Not Clear Faults 1 = Clear Faults
0x0005	4	Direction	Modbus Address 06 05 0 0 = No Command 0 1 = Forward Command 1 0 = Reverse Command 1 1 = Hold Direction Control
0x0006	5		
0x0007	6	Local Control	0 = No Local Control 1 = Local Control
0x0008	7	MOP Increment	0 = Not Increment 1 = Increment
0x0009	8	Accel Rate	Modbus Address 10 09 0 0 = No Command 0 1 = Accel Rate 1 Command 1 0 = Accel Rate 2 Command 1 1 = Hold Accel Rate
0x0010	9		
0x0011	10	Decel Rate	Modbus Address 12 11 0 0 = No Command 0 1 = Decel Rate 1 Command 1 0 = Decel Rate 2 Command 1 1 = Hold Decel Rate
0x0012	11		
0x0013	12	Reference Select	Modbus Address 15 14 13 0 0 0 = No Command 0 0 1 = Ref 1 (Ref A Select) 0 1 0 = Ref 2 (Ref B Select) 0 1 1 = Ref 3 (Preset 3) 1 0 0 = Ref 4 (Preset 4) 1 0 1 = Ref 5 (Preset 5) 1 1 0 = Ref 6 (Preset 6) 1 1 1 = Ref 7 (Preset 7)
0x0014	13		
0x0015	14		
0x0016	15	MOP Decrement	0 = Not Decrement 1 = Decrement

⁽¹⁾ A 0 = Not Stop condition (logic 0) must first be present before a 1 = Start condition will start the drive.

⁽²⁾ To perform this command, the value must change from "0" to "1."

[Table 4.F](#) shows the register outputs. These outputs must be used for writing multi-bit commands and the Reference.

Table 4.F Logic Command and Reference: Register Outputs

Modbus Address	Output Description	Values
4x0001	Product Logic Command	16-bit word. Bit definitions for PowerFlex 70/700 drives are in Table 4.E . For other products, refer to their documentation.
4x0002	Reference Lo	Bit 0...15 of 32-bit reference.
4x0003 ⁽¹⁾	Reference Hi	Bit 16...31 of 32-bit reference or the whole 16-bit reference.

⁽¹⁾ The reference value is sent only when accessing address 4x0003. If a 32-bit reference is used, the 32-bit value will be merged together by register 4x0002 and 4x0003 when accessing address 4x0003.

Viewing the Logic Status and Feedback

On Modbus RTU, there are two ways to view the logic status: discrete inputs ([Table 4.G](#)) and register inputs ([Table 4.H on page 4-8](#)). You can use discrete inputs when you need to view only one bit in the logic status word. For example, to view whether a PowerFlex 70/700 drive is Ready (bit 0), you can use a discrete input (Modbus Address 1x0001).

When you need to view multi-bit fields in the logic status word or to view the entire logic status word, you must use a register input to maintain data integrity. For example, to view the local control of a PowerFlex 70/700 drive (bits 9...11), you must use a register input (Modbus Address 3x0001).

To view the Feedback, you must also use a register input (Modbus Address 3x0002 and/or 3x0003). For details about how the feedback is scaled, refer to the [Setting the Logic Command and Reference on page 4-5](#).

[Table 4.G](#) shows that there are 16 discrete points to represent the status word bit by bit. These points can be used only for reading single-bit status.

Table 4.G Logic Status: Discrete Inputs (to Controller from Drive)

Modbus Address	Logic Status Bit	PowerFlex 70/700 Example	
		Description	Values
1x0001	0	Ready	0 = Not Ready 1 = Ready
1x0002	1	Active	0 = Not Running 1 = Running
1x0003	2	Command Direction	0 = Reverse 1 = Forward
1x0004	3	Actual Direction	0 = Reverse 1 = Forward
1x0005	4	Accel	0 = Not Accelerating 1 = Accelerating
1x0006	5	Decel	0 = Not Decelerating 1 = Decelerating
1x0007	6	Alarm	0 = No Alarm 1 = Alarm
1x0008	7	Fault	0 = No Fault 1 = Fault
1x0009	8	At Speed	0 = Not At Reference 1 = At Reference

Table 4.G Logic Status: Discrete Inputs (to Controller from Drive) (Continued)

Modbus Address	Logic Status Bit	PowerFlex 70/700 Example	
		Description	Values
1x0010	9	Local Control	Modbus Address
1x0011	10		12 11 10
1x0012	11		0 0 0 = Port 0 (TB)
			0 0 1 = Port 1
			0 1 0 = Port 2
			0 1 1 = Port 3
			1 0 0 = Port 4
			1 0 1 = Port 5
			1 1 0 = Port 6
			1 1 1 = No Local
1x0013	12	Reference	Modbus Address
1x0014	13		16 15 14 13
1x0015	14		0 0 0 0 = Ref A Auto
1x0016	15		0 0 0 1 = Ref B Auto
			0 0 1 0 = Preset 2 Auto
			0 0 1 1 = Preset 3 Auto
			0 1 0 0 = Preset 4 Auto
			0 1 0 1 = Preset 5 Auto
			0 1 1 0 = Preset 6 Auto
			0 1 1 1 = Preset 7 Auto
			1 0 0 0 = Term Blk Manual
			1 0 0 1 = DPI 1 Manual
			1 0 1 0 = DPI 2 Manual
			1 0 1 1 = DPI 3 Manual
			1 1 0 0 = DPI 4 Manual
			1 1 0 1 = DPI 5 Manual
			1 1 1 0 = DPI 6 manual
			1 1 1 1 = Jog Ref

[Table 4.H](#) shows the register inputs. These inputs must be used for reading multi-bit status fields and the Feedback.

Table 4.H Logic Status and Feedback: Register Inputs

Modbus Address	Input Description	Values
3x0001	Product Status Word	16-bit word. Bit definitions for PowerFlex 70/700 drives are in Table 4.G . For other products, refer to their documentation.
3x0002	Feedback Lo	Bit 0...15 of 32-bit feedback
3x0003 ⁽¹⁾	Feedback Hi	Bit 16...31 of 32-bit feedback or the whole 16-bit feedback.

⁽¹⁾ The Feedback value is refreshed only when accessing address 3x0003. This is to maintain data integrity.

Accessing Drive Parameters

There are two methods for accessing drive parameters: the direct access method and the pointer access method.

Direct Access Method

You can use Function Code 03 to read and Function Codes 06 (single) and 16 (multiple) to write, to directly access the drive parameters (see [Table 4.B on page 4-2](#)). This allows direct access of parameters in a single read or write as opposed to first having to write the “Param# for INx” or “Param# for OUTx” using the Pointer Access Method.

When a 41000 or higher Modbus address is used, the adapter assumes the controller is accessing the drive’s parameters directly. The address is determined by:

16-bit Adapter Mode: Modbus Address = 41000 + (Drive Parameter #)

32-bit Adapter Mode: Modbus Address = 41000 + (Drive Parameter # x 2)

For example, with the adapter in 16-bit mode, Parameter 1 is accessed by Modbus Address 41000. In the 32-bit mode, Parameter 1 is accessed by Modbus Address 41002. Any attempts to access a parameter number that does not exist will return an error.

The 32-bit adapter mode requires a minimum of two registers to read or write, and is always an even number since two 16-bit registers are read for each 32-bit data item.


Pointer Access Method

Reading Parameter Values

With a configurable input point, you can read any 16-bit parameter in the drive. The sequence for reading parameter values is as follows:

1. Set one or more Param# for INx points in the controller to the parameter number(s) that you want to read. You can set up to eight Param# for INx points. Refer to [Table 4.I on page 4-10](#).
2. Send a message with a Write Single Register (code 06) or Write Multiple Register (code 16) function. You need to send the Param# for INx point(s) to the adapter only one time per power cycle because, when the adapter receives the Param# for INx point(s), it stores them in its RAM. The adapter then continuously reads the values for the drive parameters specified in the Param# for INx points.
3. Send a message with a Read Input Registers (code 04) function. The adapter reads the drive parameter(s) that have been configured in the Param# for IN point(s) and returns their values in the User INx point(s). It can return up to eight User INx points. Refer to [Table 4.I on page 4-10](#). You can perform Read Input Registers continuously, if desired.

Figure 4.1 Configurable Input Point Operations



With the adapter in 16-bit mode, 8 User IN items are available.

Table 4.I Configurable Objects Inputs with Adapter in 16-bit Mode

Modbus Address	Data Direction	Description	Values	User Default
3x0004	Register Input	User IN1	Depends on parameter selected	0
3x0005		User IN2		
3x0006		User IN3		
3x0007		User IN4		
3x0008		User IN5		
3x0009		User IN6		
3x0010		User IN7		
3x0011		User IN8		
4x0004	Register Output	Param # for IN1	0 = Not in use - or - 1 to maximum parameter #	0
4x0005		Param # for IN2		
4x0006		Param # for IN3		
4x0007		Param # for IN4		
4x0008		Param # for IN5		
4x0009		Param # for IN6		
4x0010		Param # for IN7		
4x0011		Param # for IN8		

16-bit Mode Example: Write a value of “12” to register 4x0004. Read register 3x0004 to read the 16-bit data value from drive parameter 12.

With the adapter in 32-bit mode, 4 User IN items are available.

Table 4.J Configurable Objects Inputs with Adapter in 16-bit Mode

Modbus Address	Data Direction	Description	Values	User Default
3x0004	Register Input	User IN1 Lo	Depends on parameter selected	0
3x0005		User IN1 Hi		
3x0006		User IN2 Lo		
3x0007		User IN2 Hi		
3x0008		User IN3 Lo		
3x0009		User IN3 Hi		
3x0010		User IN4 Lo		
3x0011		User IN4 Hi		
4x0004	Register Output	Param # for IN1	0 = Not in use - or - 1 to maximum parameter #	0
4x0005		Param # for IN2		
4x0006		Param # for IN3		
4x0007		Param # for IN4		

32-bit Mode Example: Write a value of “12” to register 4x0004. Read register 3x0004 and store the returned 16-bit data. Read register 3x0005 and

store the returned 16-bit data. Use both 16-bit data items to make one 32-bit value for drive parameter 12.

Writing Parameter Values



ATTENTION: Risk of equipment damage exists. If configurable output points are programmed to write parameter data to Non-Volatile Storage (NVS) frequently, the NVS will quickly exceed its life cycle and cause the drive to malfunction. Do not create a program that frequently uses configurable outputs to write parameter data to NVS. Datalinks do not write to NVS and should be used for frequently changed parameters.

With a configurable output point, you can write a new value for any 16-bit parameter in the drive. The sequence for writing parameter values is as follows:

1. Set one or more Param# for OUTx points in the controller to the parameter number(s) to which you want to write. A value of zero in the Param# field disables the writing of data for that specific point. Refer to the drive user manual for the desired parameter number(s). You can set up to three Param# for OUTx points at a time. Refer to [Table 4.K on page 4-12](#).
2. Send a message with a Write Single Register (code 06) or Write Multiple Register (code 16) function. You need to send the Param# for OUTx point(s) to the adapter only one time per power cycle because, when the adapter receives the Param# for OUTx point(s), it stores them in its RAM.
3. Set the values that you want to write to the parameters in the User OUTx points. You can set up to three User OUTx points at a time. Refer to [Table 4.K on page 4-12](#).
4. Send a message with a Write Single Register (code 06) or Write Multiple Register (code 16) function. Each time that the adapter receives the values in the User OUTx points, it writes them to the drive parameters.

Figure 4.2 Configurable Output Point Operations




Table 4.K Configurable Objects: Outputs with Adapter in 16-bit Mode

Modbus Address	Data Direction	Description	Values	User Default
4x0012	Register Output	User OUT1	Depends on parameter selected	0
4x0013		User OUT2		
4x0014		User OUT3		
4x0015		Param # for OUT1	0 = Not in use	0
4x0016		Param # for OUT2	- or -	
4x0017		Param # for OUT3	1 to maximum parameter #	

16-bit Mode Example: Write a value of “101” to register 4x0015. Write a value of “123” to register 4x0012. The drive parameter 101 value now equals 12.3.

32-bit Mode: User OUT items are not supported when using the adapter in the 32-bit mode.

Using Broadcast Messages

A Modbus RTU global broadcast feature enables you to send a command (start, stop, etc.) to all drives on the network at the same time by using Modbus Address “0.” This feature can also be used to write the same message to each network drive via a single message, for example setting Accel Time to 5 seconds in every drive.

Important: Every node capable of receiving a broadcast message will act upon the message, so it is required that broadcast messages are used only on networks of similar devices. For example, PowerFlex 70 and 700 drives use the same Logic Command structure, Reference format and the same Modbus addressing, so these could be controlled together using a broadcast message. Always check the Modbus addressing, Logic Command structure, Reference format, etc. for every node device type before designing a system with broadcast messages.

The adapter also enables you to independently scale the broadcast message Reference of its connected drive by using **Parameter 31 - [RTU Ref. Adjust]**. The scaling factor can be set from 0...200.0%. This lets the drive Reference either match the broadcast message Reference (= 100%), scale below the broadcast message Reference (<100%), or scale above the broadcast message Reference (>100%).

Adapter Parameter Direct Access

[Table 4.L](#) provides an overview of the Modbus register addresses for directly accessing the adapter parameters.

Table 4.L Adapter Parameter Direct Access Modbus Register Map

Modbus Register	Parameter Description
4x0101	DPI Port
4x0102	DPI Data Rate
4x0103	Net Addr Cfg
4x0104	Net Addr Act
4x0105	Net Rate Cfg
4x0106	Net Rate Act
4x0107	Net Parity Cfg
4x0108	Net Parity Act
4x0109	Stop Bits Act
4x0110	Net Chksum Type
4x0111	Network Timeout
4x0112	Ref/Fdbk Size
4x0113	Datalink Size
4x0114	Reset Module
4x0115	Comm Flt Action
4x0116	DPI I/O Cfg
4x0117	DPI I/O Act
4x0118	Flt Cfg Logic
4x0119	Flt Cfg Ref Lo
4x0120 ⁽¹⁾	Flt Cfg Ref Hi
4x0121	Flt Cfg A1 In Lo
4x0122 ⁽¹⁾	Flt Cfg A1 In Hi
4x0123	Flt Cfg A2 In Lo
4x0124 ⁽¹⁾	Flt Cfg A2 In Hi
4x0125	Flt Cfg B1 In Lo
4x0126 ⁽¹⁾	Flt Cfg B1 In Hi
4x0127	Flt Cfg B2 In Lo
4x0128 ⁽¹⁾	Flt Cfg B2 In Hi
4x0129	Flt Cfg C1 In Lo
4x0130 ⁽¹⁾	Flt Cfg C1 In Hi
4x0131	Flt Cfg C2 In Lo
4x0132 ⁽¹⁾	Flt Cfg C2 In Hi
4x0133	Flt Cfg D1 In Lo
4x0134 ⁽¹⁾	Flt Cfg D1 In Hi
4x0135	Flt Cfg D2 In Lo
4x0136 ⁽¹⁾	Flt Cfg D2 In Hi
4x0137	Clear Counters
4x0138	N2 Ref Scale Lo
4x0139 ⁽¹⁾	N2 Ref Scale Hi
4x0140	Stop Bits Cfg
4x0141	RTU Ref Adjust

⁽¹⁾ A write access to this register triggers a store/update of this parameter value to the internal adapter EEPROM as a 32-bit value.

Notes:

Using Metasys N2

This chapter provides information about controlling a PowerFlex 7-Class drive, setting its Reference, and accessing its parameters through configurable objects when the Metasys N2 network protocol is selected.

Topic	Page
Understanding Metasys N2	5-1
Using the Metasys N2 Point Map for I/O	5-3
Using Metasys Configurable Objects to Access Parameters	5-8



TIP: Datalinks can also be used for accessing parameters. For information about using Datalinks, refer to [Chapter 7, Using Datalinks with All Protocols](#).

Understanding Metasys N2

Metasys nodes are built up by the use of several virtual objects. The Metasys N2 master performs read and write commands to these virtual objects, and the adapter transfers/translates the data between these virtual objects and the drive.

When a read or write command occurs to a certain dedicated virtual object, data in the virtual objects is refreshed from or transferred to the drive.

The Metasys N2 master performs read and write commands to the virtual objects one at a time. The data types that are used in the virtual objects are binary input (BI), binary output (BO), analog input (AI), analog output (AO), and internal integer (ADI), which is a 16-bit data value.

The Metasys master also performs cyclic polling of all the virtual objects.

Device Identity

The 20-COMM-H adapter must be configured in the master controller as a Vendor device (VND) Code 10 hex.

Metasys N2 Virtual Objects

A Metasys N2 node may contain up to 256 virtual objects in each of its seven different data types, called regions ([Table 5.A](#)).

Table 5.A Description of the Regions of a Virtual Object

Region	Type	Short	Description
Region 1	Analog Input	AI	32-bit, IEEE-standard floats
Region 2	Binary Input	BI	1-bit
Region 3	Analog Output	AO	32-bit, IEEE-standard floats
Region 4	Binary Output	BO	1-bit
Region 5	Internal Float	ADF	32-bit, IEEE-standard floats (Analog Data Float)
Region 6	Internal Integer	ADI	16-bit (Analog Data Integer)
Region 7	Internal Byte	DB	8-bit (Analog Data Byte)

Metasys N2 Data Types

Table 5.B Internal Structure of Metasys N2 Analog Input (AI)

Attribute	Type	Description
1	Byte	Object Configuration
2	Byte	Object Status
3	Float	Analog Input Value
8	Float	Low Alarm Limit
9	Float	Low Warning Limit
10	Float	High Warning Limit
11	Float	High Alarm Limit
12	Float	Differential

Table 5.C Internal Structure of Metasys N2 Binary Input (BI)

Attribute	Type	Description
1	Byte	Object Configuration
2	Byte	Object Status

Table 5.D Internal Structure of Metasys N2 Analog Output (AO)

Attribute	Type	Description
1	Byte	Object Configuration
2	Byte	Object Status
3	Float	Current Value

Table 5.E Internal Structure of Metasys N2 Binary Output (BO)

Attribute	Type	Description
1	Byte	Object Configuration
2	Byte	Object Status
3	Integer	Minimum On-Time
4	Integer	Minimum Off-Time
5	Integer	Maximum Cycle/Hour

Table 5.F Internal Structure of Metasys N2 Internal Integer (ADI)

Attribute	Type	Description
1	Byte	Object Status
2	Integer	Current Value. Signed 16-bit.

Using the Metasys N2 Point Map for I/O

On Metasys N2, data transfers are used to transfer the I/O data that controls the drive and sets its Reference. Note that *Output I/O* is data that the master device sends and the adapter receives. *Input I/O* is status data that the adapter sends and the master device receives.

Important: In order for the drive to use the I/O and Reference from the Metasys N2 network, you must set parameters in it and the adapter to receive the I/O and Reference. For details, refer to [Setting the I/O Configuration on page 3-5](#).

Setting the Logic Command and Reference



ATTENTION: Select and use **either** the point type Digital (BO) or the word type Analog (AO) as a control method, but **not both**. Conflicts caused from using both methods can result in dangerous operation. Failure to observe this precaution could cause bodily injury and/or damage to equipment.

On Metasys N2, there are two ways to set the logic command: binary outputs ([Table 5.L on page 5-5](#)) and an analog output ([Table 5.M on page 5-6](#)).

- When you need to set only one bit in the Logic Command word, you can use binary outputs. For example, to stop a PowerFlex 70/700 drive (bit 0), you can use a binary output (BO#1).
- When you need to set multi-bit fields in the Logic Command word or to set the entire Logic Command word, you must use the analog output to maintain data integrity. For example, to set the Reference Selection of a PowerFlex 70/700 drive (bits 12...14), you must use an analog output (AO#1).

A 16-bit product logic word is buffered in the adapter, holding the last Logic Command sent to the drive regardless of whether it was sent through the binary outputs or through product logic command outputs (AO#1). When a bit is updated through either of these outputs, a new Logic Command will be generated and sent to the drive.

To set the Reference, you must use an analog output (AO#2). [Table 5.G](#) shows example References and their results on a PowerFlex 70/700 drive that has its **Parameters 55 - [Maximum Freq]** set to 70 Hz and **82 - [Maximum Speed]** set to 60 Hz, and adapter **Parameter 29 - [N2 Ref Scale]** is set to 32,767.

Table 5.G Example Speed Reference and Feedback for a PowerFlex 70/700 Drive

Reference ⁽¹⁾		Feedback ⁽²⁾	
Percent	Speed	Speed	Percent
100%	70 Hz	60 Hz ⁽³⁾	85.7%
50%	35 Hz	35 Hz	50%
25%	17.5 Hz	17.5 Hz	25%
0%	0 Hz	0 Hz	0%

- (1) The actual value transmitted over the network is an engineering unit where 100% equals sending the value in the adapter Parameter 29 - [N2 Ref Scale], and 0% equals sending a zero.
- (2) The Feedback percent value is also scaled based on the value of adapter Parameter 29 - [N2 Ref Scale].
- (3) The drive runs at 60 Hz instead of 70 Hz because Parameter 82 - [Maximum Speed] sets 60 Hz as the maximum speed.

Reference Setup Examples

Table 5.H PowerFlex 70EC and PowerFlex 700VC Default Example

Drive Parameters		20-COMM-H Parameter	
Number	Value	Number	Value ⁽¹⁾
55 - [Maximum Freq]	130	29 - [N2 Ref Scale]	15123
82 - [Maximum Speed]	60		
298 - [DPI Ref Sel]	0 (Max Freq)		

- (1) This value is calculated as follows: $60 \div 130 \times 32767 = 15123$.

Table 5.I Maximum Freq = 70 Hz Example

Drive Parameters		20-COMM-H Parameter	
Number	Value	Number	Value ⁽¹⁾
55 - [Maximum Freq]	70	29 - [N2 Ref Scale]	28086
82 - [Maximum Speed]	60		
298 - [DPI Ref Sel]	0 (Max Freq)		

- (1) This value is calculated as follows: $60 \div 70 \times 32767 = 28086$.

Table 5.J Maximum Speed = 80 Hz Example

Drive Parameters		20-COMM-H Parameter	
Number	Value	Number	Value ⁽¹⁾
55 - [Maximum Freq]	130	29 - [N2 Ref Scale]	20164
82 - [Maximum Speed]	80		
298 - [DPI Ref Sel]	0 (Max Freq)		

- (1) This value is calculated as follows: $80 \div 130 \times 32767 = 20164$.

Table 5.K DPI Reference Scaling = Max Speed Example

Drive Parameters		20-COMM-H Parameter	
Number	Value	Number	Value ⁽¹⁾
55 - [Maximum Freq]	130	29 - [N2 Ref Scale]	32767
82 - [Maximum Speed]	60		
298 - [DPI Ref Sel]	1 (Max Speed)		

- (1) When drive parameter 298 - [DPI Ref Sel] = 1 (Max Speed), the Reference and Feedback scaling is always defined as 32767, which will cause the drive to run at the value of drive parameter 82 - [Maximum Speed]. In this example, the drive will run at 60 Hz.

[Table 5.L](#) shows that there are 16 binary outputs to represent the command word bit by bit. These outputs can be used only for writing single-bit commands.

Table 5.L Logic Command: Binary Outputs (Inputs to a Drive)

Network Point Type (NPT)	Network Point Address (NPA)	Logic Command Bit	PowerFlex 70/700 Example	
			Description	Values
BO	1	0	Stop	0 = Not Stop 1 = Stop
BO	2	1	Start ⁽¹⁾ ⁽²⁾	0 = Not Start 1 = Start
BO	3	2	Jog	0 = Not Jog 1 = Jog
BO	4	3	Clear Faults ⁽²⁾	0 = Not Clear Faults 1 = Clear Faults
BO	5	4	Direction	Network Point Addresses 06 05 0 0 = No Command 0 1 = Forward Command 1 0 = Reverse Command 1 1 = Hold Direction Control
BO	6	5		
BO	7	6	Local Control	0 = No Local Control 1 = Local Control
BO	8	7	MOP Increment	0 = Not Increment 1 = Increment
BO	9	8	Accel Rate	Network Point Addresses 10 09 0 0 = No Command 0 1 = Accel Rate 1 1 0 = Accel Rate 2 1 1 = Hold Accel Rate
BO	10	9		
BO	11	10	Decel Rate	Network Point Addresses 12 11 0 0 = No Command 0 1 = Decel Rate 1 1 0 = Decel Rate 2 1 1 = Hold Decel Rate
BO	12	11		
BO	13	12	Reference Select	Network Point Addresses 15 14 13 0 0 0 = No Command 0 0 1 = Ref 1 (Ref A Select) 0 1 0 = Ref 2 (Ref B Select) 0 1 1 = Ref 3 (Preset 3) 1 0 0 = Ref 4 (Preset 4) 1 0 1 = Ref 5 (Preset 5) 1 1 0 = Ref 6 (Preset 6) 1 1 1 = Ref 7 (Preset 7)
BO	14	13		
BO	15	14		
BO	16	15	MOP Decrement	0 = Not Decrement 1 = Decrement

⁽¹⁾ A 0 = Not Stop condition (logic 0) must first be present before a 1 = Start condition will start the drive.

⁽²⁾ To perform this command, the value must change from "0" to "1."


[Table 5.M](#) shows the analog outputs. These outputs must be used for writing multi-bit commands and the Reference.

Table 5.M Logic Command and Reference: Analog Outputs

Network Point Type (NPT)	Network Point Address (NPA)	Parameter Description	Range
AO	1	Product Logic Command	16-bit word. Bit definitions for PowerFlex 70/700 drives are in Table 5.L . For other products, refer to their documentation.
AO	2	Reference	-100.0...100.0%

Additional Configuration Specific for Metasys N2

The Reference (AO#2) for Metasys N2 is set as a percentage from -100...100%. However, the actual value transmitted over DPI is in an engineering unit that equals the entered percentage. **Parameter 29 - [N2 Ref Scale]** determines the engineering unit value sent when AO#2 is set to 100%. The relationship is linear, where:



By default, **Parameter 29 - [N2 Ref Scale]** equals 32,767, which is the maximum Reference value for PowerFlex 70/700 drives. Note that additional scaling is performed in the PowerFlex 70/700 drive, where 32,767 equals the frequency selected in drive **Parameter 55 - [Maximum Freq]**. For other DPI hosts, refer to the documentation of the specific DPI host product.

Viewing the Logic Status and Feedback

On Metasys N2, there are two ways to view the Logic Status: binary inputs ([Table 5.N on page 5-7](#)) and an analog input ([Table 5.O on page 5-8](#)). You can use binary inputs when you need to view only one bit in the Logic Status word. For example, to view whether a PowerFlex 70/700 drive is ready (bit 0), you can use a binary input (BI 1).

When you need to view multi-bit fields in the Logic Status word, to view the entire Logic Status word, or to view the Feedback word, you must use an analog input. For example, to view the local control of a PowerFlex 70/700 drive (bits 9...11), you must use an analog input (AI #1). To view the Feedback, you must use an analog input (AI #2 or AI #3).

[Table 5.N](#) shows that there are 16 binary inputs to represent the status word bit by bit. These inputs can be used only for reading single-bit status.

Table 5.N Logic Status: Binary Inputs (Output from a Drive)

Network Point Type (NPT)	Network Point Address (NPA)	Logic Status Bit	PowerFlex 70/700 Example	
			Description	Values
BI	1	0	Ready	0 = Not Ready 1 = Ready
BI	2	1	Active	0 = Not Running 1 = Running
BI	3	2	Command Direction	0 = Reverse 1 = Forward
BI	4	3	Actual Direction	0 = Reverse 1 = Forward
BI	5	4	Accel	0 = Not Accelerating 1 = Accelerating
BI	6	5	Decel	0 = Not Decelerating 1 = Decelerating
BI	7	6	Alarm	0 = No Alarm 1 = Alarm
BI	8	7	Fault	0 = No Fault 1 = Fault
BI	9	8	At Speed	0 = Not At Reference 1 = At Reference
BI	10	9	Local Control	Network Point Addresses 12 11 10 0 0 0 = Port 0 (TB) 0 0 1 = Port 1 0 1 0 = Port 2 0 1 1 = Port 3 1 0 0 = Port 4 1 0 1 = Port 5 1 1 0 = Port 6 1 1 1 = No Local
BI	11	10		
BI	12	11		
BI	13	12	Reference (typically used when commanding drive speed from source other than Metasys)	Network Point Addresses 16 15 14 13 0 0 0 0 = Ref A Auto 0 0 0 1 = Ref B Auto 0 0 1 0 = Preset 2 Auto 0 0 1 1 = Preset 3 Auto 0 1 0 0 = Preset 4 Auto 0 1 0 1 = Preset 5 Auto 0 1 1 0 = Preset 6 Auto 0 1 1 1 = Preset 7 Auto 1 0 0 0 = Term Blk Manual 1 0 0 1 = DPI 1 Manual 1 0 1 0 = DPI 2 Manual 1 0 1 1 = DPI 3 Manual 1 1 0 0 = DPI 4 Manual 1 1 0 1 = DPI 5 Manual 1 1 1 0 = DPI 6 Manual 1 1 1 1 = Jog Ref
BI	14	13		
BI	15	14		
BI	16	15		

[Table 5.O on page 5-8](#) shows the analog inputs. These inputs must be used for reading multi-bit status fields and the Feedback.

Table 5.O Logic Status and Feedback: Analog Inputs

Network Point Type (NPT)	Network Point Address (NPA)	Parameter Description	Range
AI	1	Product Status Word	16-bit word. Bit definitions for PowerFlex 70/700 drives are in Table 5.N . For other products, refer to their documentation.
AI	2	Feedback Lo	-100.0...100.0%

Using Metasys Configurable Objects to Access Parameters

Configurable objects are inputs and outputs that let you read and write parameter values. These objects handle only 16-bit parameter values.

Reading Parameter Values

The configurable points may show any 16-bit parameter in the drive by configuring the Param# point. The Param# for INx points are stored in the RAM in the adapter and need to be written to only one time per power cycle.

The adapter reads the value of the drive parameter configured in the Param# point and shows the result in the User INx point. The adapter reads the parameter values from the drive continuously one at a time when Param# is set to a non-zero value. See [Figure 5.1](#) and [Table 5.P](#).

Figure 5.1 Configurable Input Point Operation Objects Inputs




Table 5.P Configurable Objects: Inputs

Network Point Type (NPT)	Network Point Address (NPA)	Name	Description	Default
AI	3	User IN1	User-defined Input 1	0
AI	4	User IN2	User-defined Input 2	0
AI	5	User IN3	User-defined Input 3	0
AI	6	User IN4	User-defined Input 4	0
ADI	1	Param # for IN1	0 (not in use), 1 to maximum # of drive parameters	0
ADI	2	Param # for IN2	0 (not in use), 1 to maximum # of drive parameters	0
ADI	3	Param # for IN3	0 (not in use), 1 to maximum # of drive parameters	0
ADI	4	Param # for IN4	0 (not in use), 1 to maximum # of drive parameters	0

Table 5.Q Example of Configurable Objects: Inputs

Network Point Type (NPT)	Network Point Address (NPA)	Name	Description	Default
AI	3	Output Frequency	-400...400 Hz [0.1 Hz]	60.0
AI	4	Output Current	0.0 to Drive Related Amps [0.1 A]	14.0
AI	5	Output Voltage	0.0 to Drive Related Volts [0.1 VAC]	460.0
AI	6	Output Power	0.0 to Drive Related kW [0.1 kW]	7.5
ADI	1	Param # for IN1	Integer # of drive parameter	1
ADI	2	Param # for IN2	Integer # of drive parameter	3
ADI	3	Param # for IN3	Integer # of drive parameter	6
ADI	4	Param # for IN4	Integer # of drive parameter	7

Writing Parameter Values



ATTENTION: Risk of equipment damage exists. If configurable outputs are programmed to write parameter data to Non-Volatile Storage (NVS) frequently, the NVS will quickly exceed its life cycle and cause the drive to malfunction. Do not create a program that frequently uses configurable outputs to write parameter data to NVS. Datalinks do not write to NVS and should be used for frequently changed parameters.

These outputs are written from the adapter each time the User OUT point is written from the network.

► **TIP:** Analog Data Integers (ADIs) are configured by first selecting an Analog Output (AO) setpoint and then selecting the ADI.

A value of zero in the Param# field disables the writing of data for that specific point. Refer to the drive user manual for the desired parameter number.

Figure 5.2 Configurable Objects: Outputs**Table 5.R Configurable Objects: Outputs**

Network Point Type (NPT)	Network Point Address (NPA)	Description	Range	Default
AO	3	User OUT1	User-defined Output 1	0
AO	4	User OUT2	User-defined Output 2	0
ADI	5	Param# for OUT1	0 (not in use), 1 to maximum # of drive parameters	0
ADI	6	Param# for OUT2	0 (not in use), 1 to maximum # of drive parameters	0

Notes:

Using Siemens Building Technologies P1 FLN

This chapter provides information about controlling a PowerFlex 7-Class drive, setting its Reference, and accessing its parameters through points when the Siemens Building Technologies P1 FLN network protocol is selected.

Topic	Page
Understanding Siemens Building Technologies P1 FLN	6-1
Using the P1 FLN Point Map for I/O	6-5
Using the P1 FLN Point Map to Access Parameters	6-9



TIP: Datalinks can also be used for accessing parameters. For information about using Datalinks, refer to [Chapter 7, Using Datalinks with All Protocols](#).



ATTENTION: Risk of injury or equipment damage exists. On P1 FLN networks, 16-bit values are truncated to 15-bit values. Unpredictable operation may result from using **non-15-bit** drive parameters with the configurable points. Recognize the data range limitation of P1 FLN and understand the data value ranges of each parameter to be accessed over the network. Refer to the drive user manual for information about drive parameter sizes.

Understanding Siemens Building Technologies P1 FLN

P1 FLN nodes are built by the use of several points. The P1 FLN master controller performs read and write commands to these points, and the adapter transfers/translates the data between these points and the drive.

All values (byte-sized, Boolean, and true integers) are represented in a 16-bit word over the network, where the sign bit is always positive. The actual range allowed by P1 FLN, however, is always 15 bits: 0...32767 for integers, 0...255 for bytes, and 0 or 1 for Boolean. The limit of 15 bits prevents the use of the adapter's P1 FLN mode with 32-bit DPI hosts, where either Reference/Feedback or Datalink values are represented in 32-bit format. 16-bit real values will be truncated to show only 15-bit values.

P1 FLN Point Types

Logic analog and digital I/O points are used for controlling the drive, monitoring status, and reading/writing parameters. [Table 6.A](#) shows the four point types.

Table 6.A Point Types

Abbreviation	Name	Used for
LDI	Logical Digital Inputs	Reading bit level points (0 or 1) such as drive status. For example, FWD.REV MON (point 21) provides the status of the rotation direction of the drive.
LDO	Logical Digital Outputs	Writing bit-level points (0 or 1) such as drive commands. For example, CMD RUN.STOP (Point 24) commands the drive to run.
LAI	Logical Analog Inputs	Reading word-level points such as FREQ OUTPUT (Point 03) and CURRENT (Point 06).
LAO	Logical Analog Outputs	Writing word-level points such as REFERENCE (Point 92) and acceleration (Point 31).

Some points can be unbundled. Unbundle means that you can characterize the subpoint so that three additional items can be enabled for that specific subpoint:

- The subpoint can be monitored for COV (Change of Value). All unbundled points are reported for any change of value when a “Scan for COV” command is issued. (Analog points may have COV limits defined to reduce network traffic.)
- The subpoint can be overridden by the operator.
- Unbundling a point allows the operator to set up a virtual point in the controller's database, which when commanded, can also affect the subpoints in the device.

Siemens Building Technologies P1 FLN Point Map

Table 6.B Siemens Building Technologies P1 FLN Point List

Point Number ⁽¹⁾	Point Type ⁽²⁾	Descriptor	English Units	Slope	Intercept	ON Text	OFF Text	Default	Range	COV ⁽⁴⁾	Description
01	LAO	CTRL ADDRESS		1	0			99	0 – 255	No	Node address of this device.
02	LAO	APPLICATION		1	0			2718	0 – 32767	No	Firmware application number.
{03}	LAI	FREQ OUTPUT	HZ	0.01	-163.83			0	0 – 32767	Yes	Drive speed in frequency (Hertz).
{04}	LAI	PCT OUTPUT	PCT	0.1	0			0	0 – 32767	Yes	Drive speed in percentage of max.
{05}	LAI	SPEED	RPM	1	0			0	0 – 32767	Yes	Drive speed in RPM.
{06}	LAI	CURRENT	AMPS	0.1	0			0	0 – 32767	Yes	Drive current consumption in amps.
{07}	LAI	TORQUE	PCT	0.1	-1638.3			0	0 – 32767	Yes	Drive torque in percentage of max.
{08}	LAI	POWER	KW	0.1	0			0	0 – 32767	Yes	Drive power in kW.
{09}	LAI	DRIVE TEMP	DEG C	0.1	-1638.3			0	0 – 32767	Yes	Drive temperature in degree C.
{11}	LAI	DRIVE MWH	MWH	0.1	0			0	0 – 32767	Yes	Drive total power consumption in MWH.
{12}	LAI	RUN TIME	HRS	0.1	0			0	0 – 32767	Yes	Drive total run time in hours.
{13}	LAI	DC-BUS VOLT	VOLTS	0.1	0			0	0 – 32767	Yes	Drive DC bus voltage.
{20}	LAO	OVRD TIME		1	0			0	0 – 255	Yes	Not used by this application.
{21}	LDI	FWD.REV MON		1	0	REV	FWD	0 (FWD)	0 – 1	Yes	Monitor the rotation direction of the drive.
{22}	LDO	CMD.FWD.REV		1	0	REV	FWD	0 (FWD)	0 – 1	Yes	Command the rotation direction of the drive.
{23}	LDI	RUN.STOP MON		1	0	RUN	STOP	0 (STOP)	0 – 1	Yes	Monitor the Run/Stop status of the drive.
{24}	LDO	CMD.RUN.STOP		1	0	RUN	STOP	0 (NO)	0 – 1	Yes	Command Run to the drive. A STOP issues a momentary Stop command to the drive.
{25}	LDI	READY		1	0	READY	NOTRDY	0 (NOTRDY)	0 – 1	Yes	Monitor the Ready status of the drive.
{26}	LDO	RUN ENABLE		1	0	ENABLE	STOP	0 (NO)	0 – 1	Yes	Must be set to ENABLE to allow controlling the drive.
{29}	LDO	DAY.NGT		1	0	NIGHT	DAY	0 (DAY)	0 – 1	Yes	Not used by this application.
{30}	LAO	CURRNT LIMIT		0.1	0			⁽³⁾	0 – 255	No	Current limit of the drive. Min value 0.9; max value 6.0
{31}	LAO	ACCEL TIME		0.1	0			⁽³⁾	0 – 32767	No	Acceleration time of the drive. Min value 0.1; max value 3276.7
{32}	LAO	DECEL TIME		0.1	0			⁽³⁾	0 – 32767	No	Deceleration time of the drive. Min value 0.1; max value 3276.7
36	LAO	PARAM IN		1	0			0	0 – 32767	No	Parameter number to User In point.
{37}	LAI	USER IN		1	0			0	0 – 32767	Yes	User-defined input.
38	LAO	PARAM OUT		1	0			0	0 – 32767	No	Parameter number to USER IN point.
39	LAO	USER OUT		1	0			0	0 – 32767	No	User-defined output.
{44}	LAI	DLINK A1 OUT		1	0			0	0 – 32767	Yes	Bits 0-14 of Datalink Out A1.

⁽¹⁾ Points not listed are not used in this application. Point numbers that appear in braces { } may be unbundled.

⁽²⁾ For a description of point types, refer to [Table 6.A on page 6-2](#). Note that the outputs and inputs are from the network perspective, not the drive perspective. For example, an LAO is an output from the controller on the network, but it is an input to the drive.

⁽³⁾ Depends on DPI Host product connected to (PowerFlex 70, etc.) and HP size.

⁽⁴⁾ COV indicates whether the points is able to support COVs and overrides.

Table 6.B Siemens Building Technologies P1 FLN Point List (Continued)

Point Number ⁽¹⁾	Point Type ⁽²⁾	Descriptor	English Units	Slope	Intercept	ON Text	OFF Text	Default	Range	COV ⁽³⁾	Description
{46}	LAI	DLNK A2 OUT		1	0			0	0 – 32767	Yes	Bits 0-14 of Datalink Out A2.
{48}	LAI	DLNK B1 OUT		1	0			0	0 – 32767	Yes	Bits 0-14 of Datalink Out B1.
{50}	LAI	DLNK B2 OUT		1	0			0	0 – 32767	Yes	Bits 0-14 of Datalink Out B2.
{52}	LAI	DLNK C1 OUT		1	0			0	0 – 32767	Yes	Bits 0-14 of Datalink Out C1.
{54}	LAI	DLNK C2 OUT		1	0			0	0 – 32767	Yes	Bits 0-14 of Datalink Out C2.
{56}	LAI	DLNK D1 OUT		1	0			0	0 – 32767	Yes	Bits 0-14 of Datalink Out D1.
{58}	LAI	DLNK D2 OUT		1	0			0	0 – 32767	Yes	Bits 0-14 of Datalink Out D2.
{60}	LAI	INPUT REF 1		0.001	-16.383			0	0 – 32767	Yes	Shows the Input Reference 1 parameter.
{61}	LAI	INPUT REF 2		0.001	-16.383			0	0 – 32767	Yes	Shows the Input Reference 2 parameter.
{62}	LAO	DLNK A1 IN		1	0			0	0 – 32767	Yes	Bits 0-14 of Datalink In A1.
{64}	LAO	DLNK A2 IN		1	0			0	0 – 32767	Yes	Bits 0-14 of Datalink In A2.
{66}	LAO	DLNK B1 IN		1	0			0	0 – 32767	Yes	Bits 0-14 of Datalink In B1.
{68}	LAO	DLNK B2 IN		1	0			0	0 – 32767	Yes	Bits 0-14 of Datalink In B2.
{70}	LAO	DLNK C1 IN		1	0			0	0 – 32767	Yes	Bits 0-14 of Datalink In C1.
{72}	LAO	DLNK C2 IN		1	0			0	0 – 32767	Yes	Bits 0-14 of Datalink In C2.
{74}	LAO	DLNK D1 IN		1	0			0	0 – 32767	Yes	Bits 0-14 of Datalink In D1.
{76}	LAO	DLNK D2 IN		1	0			0	0 – 32767	Yes	Bits 0-14 of Datalink In D2.
{89}	LAO	LOGIC CMD LO		1	0			0	0 – 255	Yes	Lower 8 bits of Product Logic Command Word.
{90}	LAO	LOGIC CMD HI		1	0			0	0 – 255	Yes	Higher 8 bits of Product Logic Command Word.
{91}	LAI	FEEDBACK		1	0			0	0 – 32767	Yes	Feedback value bits 0-14 (absolute value).
{92}	LAO	REFERENCE		1	0			0	0 – 32767	Yes	Reference value bits 0-14.
{93}	LDI	OK FAULT		1	0	FAULT	OK	0 (OK)	0 – 1	Yes	Shows if the drive is faulted or not.
{94}	LDO	RESET FAULT		1	0	RESET	NORMAL	0 (NORMAL)	0 – 1	Yes	Resets the fault condition in the drive. Special point. Will return to NORMAL (0) automatically.
{95}	LAI	LOGIC STS LO		1	0			0	0 – 255	Yes	Lower 8 bits of Product Logic Status Word.
{96}	LAI	LOGIC STS HI		1	0			0	0 – 255	Yes	Higher 8 bits of Product Logic Status Word.
{99}	LAO	ERROR STATUS		1	0			0	0 – 255	Yes	Not used by this application.

(1) Points not listed are not used in this application. Point numbers that appear in braces { } may be unbundled.

(2) For a description of point types, refer to [Table 6.A on page 6-2](#). Note that the outputs and inputs are from the network perspective, not the drive perspective. For example, an LAO is an output from the controller on the network, but it is an input to the drive.

(3) COV indicates whether the points is able to support COVs and overrides.

Using the P1 FLN Point Map for I/O

On Siemens Building Technologies P1 FLN, data transfers are used to transfer the I/O data that controls the drive and sets its Reference. Note that *Output I/O* is data that the master device sends and the adapter receives. *Input I/O* is status data that the adapter sends and the master device receives.

Important: In order for the drive to use the I/O and Reference from the P1 FLN network, you must set parameters in it and the adapter to receive the I/O and Reference. For details, refer to [Setting the I/O Configuration on page 3-5](#).

Setting the Logic Command and Reference



ATTENTION: Select and use **either** the point type Digital (LDO) or the word type Analog (LAO) as a control method, but **not both**. Conflicts caused from using both methods can result in dangerous operation. Failure to observe this precaution could cause bodily injury and/or damage to equipment.

On Siemens Building Technologies P1 FLN, there are two ways to control a drive and set its Reference.

- The more common way uses points such as CMD RUN.STOP (point 24) and RUN ENABLE (point 26). Refer to [Table 6.B on page 6-3](#) for a list of points. For example, to start a PowerFlex 70/700 drive, you can set CMD RUN.STOP (point 24) to “RUN.” To stop it, you can set CMD RUN.STOP (point 24) to “STOP” or RUN ENABLE (point 26) to “STOP.”



ATTENTION: LOGIC CMD LO (point 89) must be written prior to LOGIC CMD HI (point 90) to maintain data integrity of the Logic Command word. Failure to observe this precaution could result in bodily injury and/or damage to equipment.

- The second way uses LOGIC CMD HI (point 90) and LOGIC CMD LO (point 89). The LOGIC CMD LO and LOGIC CMD HI points are both 8-bit points. The adapter joins these two words together to make a 16-bit command word. Refer to [Appendix C, Logic Command/Status Words](#), for definitions of the bits in the command word. The command word in the adapter’s buffer is updated with the content of LOGIC CMD LO and LOGIC CMD HI points. It is transferred to the drive when LOGIC CMD HI is written. Therefore, to maintain data integrity of the command word, LOGIC CMD LO must be written prior to writing LOGIC CMD HI. For example, to start a PowerFlex 70/700 drive, you can write a value of “2” to LOGIC CMD LO and a value of “0” to LOGIC CMD HI. To stop it, you can write a value of “1” to LOGIC CMD LO and a value of “0” to LOGIC CMD HI.

The Reference value is a 16-bit value in the drive but will only use 15 bits due to the P1 FLN protocol limitation. You can send the reference using REFERENCE (point 92). Remember that the Reference value is a scaled

engineering value. For example, in PowerFlex 70/700 drives, the Reference is scaled based on the value of **Parameter 55 - [Maximum Freq]**, but the commanded maximum speed can never exceed the value of **Parameter 82 - [Maximum Speed]**. [Table 6.C](#) shows example References and their results on a PowerFlex 70/700 drive that has its **Parameters 55 - [Maximum Freq]** set to 130 Hz and **82 - [Maximum Speed]** set to 60 Hz.

Table 6.C Example Speed Reference and Feedback for a PowerFlex 70/700

Reference Value	Scale		Output Speed	Feedback Value
	Percent	Value		
32767	100%	130 Hz	60 Hz ⁽¹⁾	15123 ⁽²⁾
16384	50%	65 Hz	60 Hz ⁽¹⁾	15123
8192	25%	32.5 Hz	32.5 Hz	8192
0	0%	0 Hz	0 Hz	0

⁽¹⁾ The drive runs at 60 Hz instead of 130 Hz because Parameter 82 - [Maximum Speed] sets 60 Hz as the maximum speed.

⁽²⁾ The Feedback value is also scaled based on the value of Parameter 55 - [Maximum Freq]. For example, $60/130 = 0.46$ so $32767 \times 0.46 = 15123$.

[Table 6.D](#) shows the commands that you can execute on a PowerFlex 70/700 drive and the point(s) that you can use to execute them.

Table 6.D Logic Commands

Point Number(s)	Point	Logic Command Bit	PowerFlex 70/700 Example	
			Description	Values
24	CMD RUN.STOP	0	Stop ⁽¹⁾	0 = Not Stop 1 = Stop ⁽³⁾
26	RUN ENABLE			
89	LOGIC CMD LO bit 0			
24	CMD RUN.STOP	1	Start ^{(1) (2)}	0 = Not Start 1 = Start
89	LOGIC CMD LO bit 0			
89	LOGIC CMD LO bit 2	2	Jog	0 = Not Jog 1 = Jog
94	RESET FAULTS	3	Clear Faults ⁽²⁾	0 = Not Clear Faults 1 = Clear Faults
89	LOGIC CMD LO bit 3			
22	CMD FWD.REV	4 and 5	Direction	Bits 05 04 0 0 = No Command 0 1 = Forward Command 1 0 = Reverse Command 1 1 = Hold Direction Control
89	LOGIC CMD LO bits 4, 5			
89	LOGIC CMD LO bit 6	6	Local Control	0 = No Local Control 1 = Local Control
89	LOGIC CMD LO bit 7	7	MOP Increment	0 = Not Increment 1 = Increment
90	LOGIC CMD HI bits 0, 1	8 and 9	Accel Rate	LOGIC CMD HI Bits 01 00 0 0 = No Command 0 1 = Accel Rate 1 1 0 = Accel Rate 2 1 1 = Hold Accel Rate
90	LOGIC CMD HI bits 3, 2			
90	LOGIC CMD HI bits 3, 2	10 and 11	Decel Rate	LOGIC CMD HI Bits 03 02 0 0 = No Command 0 1 = Decel Rate 1 1 0 = Decel Rate 2 1 1 = Hold Decel Rate
90	LOGIC CMD HI bits 3, 2			

Table 6.D Logic Commands (Continued)

Point Number(s)	Point	Logic Command Bit	PowerFlex 70/700 Example	
			Description	Values
90	LOGIC CMD HI bits 6, 5, 4	12, 13, and 14	Reference Select	Bits 06 05 04 0 0 0 = No Command 0 0 1 = Ref 1 (Ref A Select) 0 1 0 = Ref 2 (Ref B Select) 0 1 1 = Ref 3 (Preset 3) 1 0 0 = Ref 4 (Preset 4) 1 0 1 = Ref 5 (Preset 5) 1 1 0 = Ref 6 (Preset 6) 1 1 1 = Ref 7 (Preset 7)
90	LOGIC CMD HI bit 7	15	MOP Decrement	0 = Not Decrement 1 = Decrement

(1) A 0 = Not Stop condition (Logic Command bit 0) must first be present before a 1 = Start condition will start the drive.

(2) To perform this command, the value must change from "0" to "1."

(3) Setting CMD.RUN.STOP to STOP issues a momentary Stop command to the drive. Logic Command Bit 0 is momentarily set to 1 (STOP) to initiate a Stop and then set to 0 (Not Stop).

The P1 FLN point map provides points to execute other commands on an adapter or drive. These points include CTRL ADDRESS (point 01), CURRENT LIMIT (point 30), ACCEL TIME (point 31), and DECEL TIME (point 32). Refer to [Table 6.E on page 6-8](#) for a description of the various points.

Viewing the Logic Status and Feedback

There are two ways to determine drive status:

- The more common way uses points such as RUN.STOP MON (point 23) and FWD.REV MON (point 21) that represent individual bits in the Logic Status word. Refer to [Table 6.B on page 6-3](#) for a list of points. For example, to view if a PowerFlex 70/700 drive is running, you can read RUN.STOP MON (point 23) to see if it is "RUN" or "STOP." To view its direction, you can read FWD.REV MON (point 21) to see if it is "FWD" or "REV."
- The second way uses LOGIC STS LO (point 95) and LOGIC STS HI (point 96). The LOGIC STS LO and LOGIC STS HI are both 8-bit points that the adapter can use to report its 16-bit status word. Refer to [Appendix C, Logic Command/Status Words](#), for definitions of the bits in the status word. Since LOGIC STS LO gets updated only when LOGIC STS HI is read, you must read LOGIC STS HI prior to reading LOGIC STS LO to maintain the data integrity of the status word. For example, to view if a PowerFlex 70/700 drive is running, you can read LOGIC STS HI and LOGIC STS LO and determine if bit 1 is "0" (Not Running) or "1" (Running). To view its direction, you can read LOGIC STS LO and LOGIC STS HI and determine if bit 3 is "0" (Reverse) or "1" (Forward).

The Feedback can also be viewed in two ways:

- **FREQ OUTPUT** (point 03), **PCT OUTPUT** (point 04), and **SPEED** (point 05) report the feedback in values such as Hz, percent of maximum speed, and RPM, respectively.
- **FEEDBACK** (point 91) reports the feedback as a scaled value. For an explanation of how the Reference/Feedback is scaled, refer to the [Setting the Logic Command and Reference on page 6-5](#).

[Table 6.E](#) shows the status that you can view on a PowerFlex 70/700 drive and the points that you can use to view them.

Table 6.E Logic Status

Point Number(s)	Point Name	Logic Status Bit	PowerFlex 70/700 Example	
			Description	Values (1)
25	READY	0	Ready	0 = Not Ready 1 = Ready
95	LOGIC STS LO bit 0			
23	RUN.STOP MON	1	Active	0 = Not Running 1 = Running
95	LOGIC STS LO bit 1			
95	LOGIC STS LO bit 2	2	Command Direction	0 = Reverse 1 = Forward
21	FWD.REV MON	3	Actual Direction	0 = Reverse 1 = Forward
95	LOGIC STS LO bit 3			
95	LOGIC STS LO bit 4	4	Accel	0 = Not Accelerating 1 = Accelerating
95	LOGIC STS LO bit 5	5	Decel	0 = Not Decelerating 1 = Decelerating
95	LOGIC STS LO bit 6	6	Alarm	0 = No Alarm 1 = Alarm
93	OK.FAULT	7	Fault	0 = No Fault 1 = Fault
95	LOGIC STS LO bit 7			
96	LOGIC STS HI bit 0	8	At Speed	0 = Not At Reference 1 = At Reference
96	LOGIC STS HI bits 3, 2, 1	9, 10, and 11	Local Control	LOGIC STS HI Bits 03 02 01 0 0 0 = Port 0 (TB) 0 0 1 = Port 1 0 1 0 = Port 2 0 1 1 = Port 3 1 0 0 = Port 4 1 0 1 = Port 5 1 1 0 = Port 6 1 1 1 = No Local

Table 6.E Logic Status (Continued)

Point Number(s)	Point Name	Logic Status Bit	PowerFlex 70/700 Example	
			Description	Values ⁽¹⁾
96	LOGIC STS HI bits 7, 6, 5, 4	12, 13, 14, and 15	Reference	LOGIC STS HI Bits 07 06 05 04 0 0 0 0 = Ref A Auto 0 0 0 1 = Ref B Auto 0 0 1 0 = Preset 2 Auto 0 0 1 1 = Preset 3 Auto 0 1 0 0 = Preset 4 Auto 0 1 0 1 = Preset 5 Auto 0 1 1 0 = Preset 6 Auto 0 1 1 1 = Preset 7 Auto 1 0 0 0 = Term Blk Manual 1 0 0 1 = DPI 1 Manual 1 0 1 0 = DPI 2 Manual 1 0 1 1 = DPI 3 Manual 1 1 0 0 = DPI 4 Manual 1 1 0 1 = DPI 5 Manual 1 1 1 0 = DPI 6 Manual 1 1 1 1 = Jog Ref

⁽¹⁾ The values in this column are for LOGIC STS LO (point 95) and LOGIC STS HI (point 96). For details about other point values, refer to [Table 6.B on page 6-3](#).

The P1 FLN point map provides points to monitor a number of other features in the drive. These points include CURRENT (point 06), TORQUE (point 07), and POWER (point 08). Refer to [Table 6.E](#) for a description of the various points.

Using the P1 FLN Point Map to Access Parameters

Drive parameters can be accessed using Configurable Points or Datalinks ([Chapter 7, Using Datalinks with All Protocols](#)).

Reading Parameter Values

Configurable points USER IN (point 37) and PARAM IN (point 36) are points that enable any parameter in the drive to be monitored. The USER IN shows only 15-bit values; therefore, only 16-bit drive parameters can be used (however, only values between 0...32767 would be used).

The PARAM IN is used to configure which parameter is to be monitored, and the value ends up in the USER IN. For example, for a PowerFlex 70 or 700 drive, writing the value of “1” into PARAM IN point (reading drive parameter 1) would provide the Output Frequency in USER IN point.

Writing Parameter Values



ATTENTION: Risk of equipment damage exists. If configurable points are programmed to write parameter data to Non-Volatile Storage (NVS) frequently, the NVS will quickly exceed its life cycle and cause the drive to malfunction. Do not create a program that frequently uses configurable points to write parameter data to NVS. Datalinks do not write to NVS and should be used for frequently changed parameters.

Configurable Points USER OUT (point 39) and PARAM OUT (point 38) are points that enable write access to any parameter in the drive. However, due to the 15-bit limitation, only 16-bit drive parameters should be accessed.

For example, for a PowerFlex 70/700 drive, writing a value of “140” in PARAM OUT (writing drive parameter 140) and the value of “200” in USER OUT would set drive **Parameter 140 - [Accel Time 1]** to 20.0 seconds.

Using Datalinks with All Protocols

This chapter provides information and examples showing how to use Datalinks.

Topic	Page
Using Datalinks	7-1
Using Datalinks with Modbus	7-3
Using Datalinks with Metasys N2	7-4
Using Datalinks with Siemens P1 FLN	7-5

Using Datalinks

A Datalink is a mechanism used by PowerFlex drives to transfer data to and from the controller. Datalinks “point” to specific drive parameters to be accessed. When enabled, each Datalink occupies two 16-bit or two 32-bit words in both the input and output image. Adapter **Parameter 19 - [Datalink Size]** indicates whether the drive uses 16-bit or 32-bit words for Datalinks.

Rules for Using Datalinks

- Each set of Datalink parameters in a PowerFlex drive can be used by only one adapter. If more than one adapter is connected to a single drive, multiple adapters must not try to use the same Datalink.
- Parameter settings in the drive determine the data passed through the Datalink mechanism. Refer to the documentation for your drive.
- When you use a Datalink to change a value, the value is NOT written to the Non-Volatile Storage (NVS). The value is stored in volatile memory and lost when the drive loses power. Thus, use Datalinks when you need to change a value of a parameter frequently.

32-Bit Parameters using 16-Bit Datalinks

This subsection only pertains to PowerFlex 70 (SC or EC), PowerFlex 700 (SC), and PowerFlex 700H drives which use 16-bit Datalinks. To read (and/or write) a 32-bit parameter using 16-bit Datalinks, typically both Datalinks of a pair (A, B, C, D) are set to the same 32-bit parameter. For example, to read Parameter 10 - [Elapsed Run Time] in a PowerFlex 70 drive, both Datalink A1 Out and Datalink A2 Out are set to “10.” Datalink A1 Out will contain the least significant word (LSW) and Datalink A2 Out will contain the most significant word (MSW).

32-bit data is stored in binary as follows:

MSW	2^{31} through 2^{16}
LSW	2^{15} through 2^0

In this example, the Parameter 10 - [Elapsed Run Time] value of 6553.9 Hrs is read as “6553.9” in Datalink A1 Out and Datalink A2 Out.

Datalink	Word	Parameter	Data (Hex)
A1 Out	LSW	10	0003
A2 Out	MSW	10	0001

Conversion Example:

Parameter 010 - [Elapsed Run Time] = 6553.9 Hrs
 MSW = $0001_{\text{hex}} = 0001_{\text{binary}} = 2^{16} = 65536$
 LSW = $0003_{\text{hex}} = 3$
 Engineering Value = $65536 + 3 = 65539$
 Parameter 10 Displayed Value = 6553.9 Hrs

Regardless of the Datalink combination, Datalink x1 Out will always contain the LSW and Datalink x2 Out will always contain the MSW. In the following example, the PowerFlex 70 drive Parameter 242 - [Power Up Marker] contains a value of 88.4541 hours.

Datalink	Word	Parameter	Data (Hex)
A2 Out	MSW	242	000D
B1 Out	LSW	242	7F3D

Conversion Example:

Parameter 242 - [Power Up Marker] = 88.4541 hours
 MSW = $000D_{\text{hex}} = 1101_{\text{binary}} = 2^{19} + 2^{18} + 2^{16} = 851968$
 LSW = $7F3D_{\text{hex}} = 32573$
 Engineering Value = $851968 + 32573 = 884541$
 Parameter 242 Displayed Value = 88.4541 Hrs

Configuring Datalinks

Configuring Datalinks from the drive side is a two-step process:

1. Configure the datalink parameters in the drive. For example, in a PowerFlex 70 or 700 drive, set **Parameters 300 - [Data In A1]** to **317 - [Data Out D2]** to “point” to the parameters to be accessed. For instance, to read drive **Parameter 1 - [Output Freq]**, set **Parameter 310 - [Data Out A1]** to “1.”
2. Enable the desired Datalinks in **Parameter 16 - [DPI I/O Cfg]** in the adapter. This tells the adapter to transfer Datalink data to and from the drive. For example, to enable Datalink A1, set bit 1 to “1.” For details, refer to [Setting the I/O Configuration on page 3-5](#).

Using Datalinks with Modbus

This section presents information about using Datalinks with Modbus networks. For information about using Datalinks for Metasys N2 networks or Siemens P1 FLN networks, refer to the [Using Datalinks with Metasys N2](#) or [Using Datalinks with Siemens P1 FLN](#) sections in this chapter.

Modbus Datalinks Out: A...D

Table 7.A Modbus Datalinks Out - A1, A2

Modbus Address	Data Direction	Parameter Description	16-Bit Datalink	32-Bit Datalink
3x0012	Register Input	Datalink A1 Out	Not used	LSW of 32-bit
3x0013 ⁽¹⁾	Register Input	Datalink A1 Out	16-bit value	MSW of 32-bit
3x0014	Register Input	Datalink A2 Out	Not used	LSW of 32-bit
3x0015 ⁽²⁾	Register Input	Datalink A2 Out	16-bit value	MSW of 32-bit

⁽¹⁾ A read access to address 3x0013 initiates a refresh of Datalink A1 value before reading.

⁽²⁾ A read access to address 3x0015 initiates a refresh of Datalink A2 value before reading.

Table 7.B Modbus Datalinks Out - B1, B2

Modbus Address	Data Direction	Parameter Description	16-Bit Datalink	32-Bit Datalink
3x0016	Register Input	Datalink B1 Out	Not used	LSW of 32-bit
3x0017 ⁽¹⁾	Register Input	Datalink B1 Out	16-bit value	MSW of 32-bit
3x0018	Register Input	Datalink B2 Out	Not used	LSW of 32-bit
3x0019 ⁽²⁾	Register Input	Datalink B2 Out	16-bit value	MSW of 32-bit

⁽¹⁾ A read access to address 3x0017 initiates a refresh of Datalink B1 value before reading.

⁽²⁾ A read access to address 3x0019 initiates a refresh of Datalink B2 value before reading.

Table 7.C Modbus Datalinks Out - C1, C2

Modbus Address	Data Direction	Parameter Description	16-Bit Datalink	32-Bit Datalink
3x0020	Register Input	Datalink C1 Out	Not used	LSW of 32-bit
3x0021 ⁽¹⁾	Register Input	Datalink C1 Out	16-bit value	MSW of 32-bit
3x0022	Register Input	Datalink C2 Out	Not used	LSW of 32-bit
3x0023 ⁽²⁾	Register Input	Datalink C2 Out	16-bit value	MSW of 32-bit

⁽¹⁾ A read access to address 3x0021 initiates a refresh of Datalink C1 value before reading.

⁽²⁾ A read access to address 3x0023 initiates a refresh of Datalink C2 value before reading.

Table 7.D Modbus Datalinks Out - D1, D2

Modbus Address	Data Direction	Parameter Description	16-Bit Datalink	32-Bit Datalink
3x0024	Register Input	Datalink D1 Out	Not used	LSW of 32-bit
3x0025 ⁽¹⁾	Register Input	Datalink D1 Out	16-bit value	MSW of 32-bit
3x0026	Register Input	Datalink D2 Out	Not used	LSW of 32-bit
3x0027 ⁽²⁾	Register Input	Datalink D2 Out	16-bit value	MSW of 32-bit

⁽¹⁾ A read access to address 3x0025 initiates a refresh of Datalink D1 value before reading.

⁽²⁾ A read access to address 3x0027 initiates a refresh of Datalink D2 value before reading.

Modbus Datalinks In: A...D

Table 7.E Modbus Datalinks In - A1, A2

Modbus Address	Data Direction	Parameter Description	16-Bit Datalink	32-Bit Datalink
4x0018	Register Output	Datalink A1 In	Not used	LSW of 32-bit
4x0019 ⁽¹⁾	Register Output	Datalink A1 In	16-bit value	MSW of 32-bit
4x0020	Register Output	Datalink A2 In	Not used	LSW of 32-bit
4x0021 ⁽²⁾	Register Output	Datalink A2 In	16-bit value	MSW of 32-bit

⁽¹⁾ A write access to address 4x0019 initiates an update of the Datalink A1 field in the DPI I/O image.

⁽²⁾ A write access to address 4x0021 initiates an update of the Datalink A2 field in the DPI I/O image.

Table 7.F Modbus Datalinks In - B1, B2

Modbus Address	Data Direction	Parameter Description	16-Bit Datalink	32-Bit Datalink
4x0022	Register Output	Datalink B1 In	Not used	LSW of 32-bit
4x0023 ⁽¹⁾	Register Output	Datalink B1 In	16-bit value	MSW of 32-bit
4x0024	Register Output	Datalink B2 In	Not used	LSW of 32-bit
4x0025 ⁽²⁾	Register Output	Datalink B2 In	16-bit value	MSW of 32-bit

⁽¹⁾ A write access to address 4x0023 initiates an update of the Datalink B1 field in the DPI I/O image.

⁽²⁾ A write access to address 4x0025 initiates an update of the Datalink B2 field in the DPI I/O image.

Table 7.G Modbus Datalinks In - C1, C2

Modbus Address	Data Direction	Parameter Description	16-Bit Datalink	32-Bit Datalink
4x0026	Register Output	Datalink C1 In	Not used	LSW of 32-bit
4x0027 ⁽¹⁾	Register Output	Datalink C1 In	16-bit value	MSW of 32-bit
4x0028	Register Output	Datalink C2 In	Not used	LSW of 32-bit
4x0029 ⁽²⁾	Register Output	Datalink C2 In	16-bit value	MSW of 32-bit

⁽¹⁾ A write access to address 4x0027 initiates an update of the Datalink C1 field in the DPI I/O image.

⁽²⁾ A write access to address 4x0029 initiates an update of the Datalink C2 field in the DPI I/O image.

Table 7.H Modbus Datalinks In - D1, D2

Modbus Address	Data Direction	Parameter Description	16-Bit Datalink	32-Bit Datalink
4x0030	Register Output	Datalink D1 In	Not used	LSW of 32-bit
4x0031 ⁽¹⁾	Register Output	Datalink D1 In	16-bit value	MSW of 32-bit
4x0032	Register Output	Datalink D2 In	Not used	LSW of 32-bit
4x0033 ⁽²⁾	Register Output	Datalink D2 In	16-bit value	MSW of 32-bit

⁽¹⁾ A write access to address 4x0031 initiates an update of the Datalink D1 field in the DPI I/O image.

⁽²⁾ A write access to address 4x0033 initiates an update of the Datalink D2 field in the DPI I/O image.

Using Datalinks with Metasys N2

This section presents information about using Datalinks with Metasys N2 networks. For information about using Datalinks for Modbus networks or Siemens P1 FLN networks, refer to the [Using Datalinks with Modbus](#) and [Using Datalinks with Siemens P1 FLN](#) sections in this chapter.

Metasys N2 Datalinks Out: A and B (No Datalinks C and D)

Table 7.I Metasys N2 Datalinks Out - A1, A2

Network Point Type (NPT)	Network Point Address (NPA)	Direction	Parameter Description	16-Bit Datalink	32-Bit Datalink
AI	7	Input	Datalink A1 Out	16-bit value	Limited to -16,777,215...16,777,215
AI	8	Input	Datalink A2 Out	16-bit value	Limited to -16,777,215...16,777,215

Table 7.J Metasys N2 Datalinks Out - B1, B2

Network Point Type (NPT)	Network Point Address (NPA)	Direction	Parameter Description	16-Bit Datalink	32-Bit Datalink
AI	9	Input	Datalink B1 Out	16-bit value	Limited to -16,777,215...16,777,215
AI	10	Input	Datalink B2 Out	16-bit value	Limited to -16,777,215...16,777,215

Metasys N2 Datalinks In: A and B (No Datalinks C and D)

Table 7.K Metasys N2 Datalinks In - A1, A2

Network Point Type (NPT)	Network Point Address (NPA)	Direction	Parameter Description	16-Bit Datalink	32-Bit Datalink
AO	5	Output	Datalink A1 In	16-bit value	Limited to -16,777,215...16,777,215
AO	6	Output	Datalink A2 In	16-bit value	Limited to -16,777,215...16,777,215

Table 7.L Metasys N2 Datalinks In - B1, B2

Network Point Type (NPT)	Network Point Address (NPA)	Direction	Parameter Description	16-Bit Datalink	32-Bit Datalink
AO	7	Output	Datalink B1 In	16-bit value	Limited to -16,777,215...16,777,215
AO	8	Output	Datalink B2 In	16-bit value	Limited to -16,777,215...16,777,215

Using Datalinks with Siemens P1 FLN

This section presents information about using Datalinks with Siemens P1 FLN networks. For information about using Datalinks for Modbus networks or Metasys N2 networks, refer to the [Using Datalinks with Modbus](#) or [Using Datalinks with Metasys N2](#) sections in this chapter.

DLNK A1 OUT to DLNK D2 OUT contain the Datalink Out A1 to D2 parameters *from* the drive. DLNK A1 IN to DLNK D2 IN contain the Datalink In A1 to D2 parameter values *to* the drive.

For example, a PowerFlex 70 or 700 drive enabling Datalink A for the adapter and configuring drive **Parameter 310 - [Data Out A1]** to “1” will provide drive **Parameter 1 - [Output Frequency]** at the DLNK A1 OUT point. Configuring **Parameter 300 - [Data In A1]** to “140” in the drive will transfer the value of the DLNK A1 IN point value to drive **Parameter 140 - [Accel Time 1]** when accessed.

Note that certain drives may utilize 32-bit datalinks. In this case, Datalinks are not supported by the adapter. The adapter will support only 15-bit Datalink values.



ATTENTION: Risk of injury or equipment damage exists. On P1 FLN networks, 16-bit values are truncated to 15-bit values. Unpredictable operation may result from using **non-16-bit** drive parameters with the configurable points. Recognize the data range limitation of P1 FLN and understand the data value ranges of each parameter to be accessed over the network. Refer to the drive user manual for information about drive parameter sizes.

Siemens P1 FLN Datalinks Out: A...D

P1 FLN devices work only with 15-bit integer values; therefore, these points only show 15-bit values. If an adapter is connected to a host using 32-bit Datalinks, the adapter will be prevented from using Datalinks. The DPI host determines if 16- or 32-bit Datalink values are used.

Table 7.M Siemens P1 FLN Datalinks Out: A...D

Point Number ⁽¹⁾	Point Type	Descriptor	Factory Default	Description
{44}	LAI	DLINK A1 OUT	0	Bit 0...14 of Datalink Out A1
{46}	LAI	DLINK A2 OUT	0	Bit 0...14 of Datalink Out A2
{48}	LAI	DLINK B1 OUT	0	Bit 0...14 of Datalink Out B1
{50}	LAI	DLNK B2 OUT	0	Bit 0...14 of Datalink Out B2
{52}	LAI	DLNK C1 OUT	0	Bit 0...14 of Datalink Out C1
{54}	LAI	DLNK C2 OUT	0	Bit 0...14 of Datalink Out C2
{56}	LAI	DLNK D1 OUT	0	Bit 0...14 of Datalink Out D1
{58}	LAI	DLNK D2 OUT	0	Bit 0...14 of Datalink Out D2

⁽¹⁾ Point numbers that appear in braces { } may be unbundled at the field panel.

Siemens P1 FLN Datalinks In: A...D

P1 FLN devices work only with 15-bit integer values; therefore, these points only show 15-bit values. If an adapter is connected to a host using 32-bit Datalinks, the adapter will be prevented from using Datalinks. The DPI host determines if 16- or 32-bit Datalink values are used.

Table 7.N Siemens P1 FLN Datalinks In: A...D

Point Number ⁽¹⁾	Point Type	Descriptor	Factory Default	Description
{62}	LAO	DLNK A1 IN	0	Bits 0...14 of Datalink In A1
{64}	LAO	DLNK A2 IN	0	Bits 0...14 of Datalink In A2
{66}	LAO	DLNK B1 IN	0	Bits 0...14 of Datalink In B1
{68}	LAO	DLNK B2 IN	0	Bits 0...14 of Datalink In B2
{70}	LAO	DLNK C1 IN	0	Bits 0...14 of Datalink In C1
{72}	LAO	DLNK C2 IN	0	Bits 0...14 of Datalink In C2
{74}	LAO	DLNK D1 IN	0	Bits 0...14 of Datalink In D1
{76}	LAO	DLNK D2 IN	0	Bits 0...14 of Datalink In D2

⁽¹⁾ Point numbers that appear in braces { } may be unbundled at the field panel.

Troubleshooting


This chapter provides information for diagnosing and troubleshooting potential problems with the adapter and network.

Topic	Page
Understanding the Status Indicators	8-1
PORT Status Indicator	8-2
MOD Status Indicator	8-2
NET A Status Indicator	8-3
NET B Status Indicator	8-3
Viewing Adapter Diagnostic Items	8-4
Viewing and Clearing Events	8-6

Understanding the Status Indicators

The adapter has four status indicators. They can be viewed on the adapter or through the drive cover. See [Figure 8.1](#).

Figure 8.1 Status Indicators (location on drive may vary)



Item	Status Indicator	Description	Page
①	PORT	DPI Connection Status	8-2
②	MOD	Adapter Status	8-2
③	NET A	Serial Communication Status	8-3
④	NET B	Serial Communication Traffic Status	8-3

PORT Status Indicator

This red/green bicolor LED indicates the status of the adapter's DPI connection to the drive as shown in the table below.

Status	Cause	Corrective Action
Off	The adapter is not powered or is not properly connected to the drive.	<ul style="list-style-type: none"> Securely connect the adapter to the drive using the Internal Interface (ribbon) cable. Apply power to the drive.
Flashing Red	The adapter is not receiving a ping message from the drive.	<ul style="list-style-type: none"> Verify that cables are securely connected and not damaged. Replace cables if necessary. Cycle power to the drive.
Steady Red	<p>The drive has refused an I/O connection from the adapter.</p> <p>Another DPI peripheral is using the same DPI port as the adapter.</p>	<p>Important: Cycle power to the drive after making any of the following corrections:</p> <ul style="list-style-type: none"> Verify that all DPI cables on the drive are securely connected and not damaged. Replace cables if necessary. Verify that the DPI drive supports Datalinks. Configure the adapter to use a Datalink that is not already being used by another peripheral.
Steady Orange	<p>The adapter is connected to a product that does not support Rockwell Automation DPI communications.</p> <p>A connection to a host with a 32-bit reference or 32-bit Datalinks is detected when the peripheral has been configured to use the P1 FLN protocol. The peripheral doesn't support 32-bit devices when using the P1 FLN network protocol.</p>	<ul style="list-style-type: none"> Connect the adapter to a product that supports Allen-Bradley DPI communications (for example, a PowerFlex 7-Class drive). Connect the adapter to a product that uses a 16-bit reference and 16-bit Datalinks.
Flashing Green	The adapter is establishing an I/O connection to the drive or I/O has been disabled.	<ul style="list-style-type: none"> Verify the settings of Parameter 16 - [DPI I/O Cfg]. Normal behavior if all I/O is disabled in Parameter 16 - [DPI I/O Cfg].
Steady Green	The adapter is properly connected and is communicating with the drive.	No action required.

MOD Status Indicator

This red/green bicolor LED indicates the status of the adapter as shown in the table below.

Status	Cause	Corrective Action
Off	The adapter is not powered or is not properly connected to the drive.	<ul style="list-style-type: none"> Securely connect the adapter to the drive using the Internal Interface (ribbon) cable. Apply power to the drive.
Flashing Red	Bad CRC of adapter parameters or flash program; other recoverable fault condition.	<ul style="list-style-type: none"> Clear faults in the adapter. Cycle power to the drive. If cycling power does not correct the problem, the adapter parameter settings may have been corrupted. Reset defaults and reconfigure the adapter. If resetting defaults does not correct the problem, flash the adapter with the latest firmware release.
Steady Red	The adapter has failed the hardware test.	<ul style="list-style-type: none"> Cycle power to the drive. Replace the adapter.

Status	Cause	Corrective Action
Flashing Green	The adapter is operational, but is not transferring I/O data.	<ul style="list-style-type: none"> Place the scanner in RUN mode. Program the controller to recognize and transmit I/O to the adapter. Configure the adapter for the program in the controller. Normal behavior if all I/O has been disabled in Parameter 16 - [DPI I/O Cfg].
Flashing Red/ Green	The adapter has detected a framing error.	Check Parameter 09 -[Stop Bits Act] and Parameter 30 - [Stop Bits Cfg] .
Steady Green	The adapter is operational and transferring I/O data.	No action required.

NET A Status Indicator

This red/green bicolor LED indicates the receive status of the adapter as shown in the table below.

Status	Cause	Corrective Actions
Off	<p>The adapter is not powered or is not properly connected to the network.</p> <p>The first incoming network command is not yet recognized.</p>	<ul style="list-style-type: none"> Securely connect the adapter to the drive using the Internal Interface (ribbon) cable. Correctly connect the RS-485 cable to the connector. Apply power to the drive. Set the baud rate and/or parity to match the controller. Set the correct network protocol.
Flashing Red	A network connection has timed out.	<ul style="list-style-type: none"> Set the timeout in Parameter 11 - [Network Timeout]. Place the scanner in RUN mode. Verify that there is not too much traffic on the network.
Steady Red	The device has detected an error that has made it incapable of communication on the network.	<ul style="list-style-type: none"> Select the correct network protocol. Select correct data rate. Verify node address is correct. Cycle power to apply changes.
Flashing Green	<p>Online to network, but not producing or consuming I/O.</p> <p>If Parameter 11 - [Network Timeout] has not been set to "0" (zero), this indicates that the adapter has not received any messages within the interval, but it has not yet timed out. The LED will turn steady green when communication resumes.</p>	<ul style="list-style-type: none"> Place the scanner in RUN mode. Program the scanner to send messages to this specific adapter within the specified timeout. Configure the adapter for the program in the controller.
Steady Green	The adapter is properly connected and communicating on the network.	No action required.

NET B Status Indicator

This green LED indicates the transmit status of the adapter as shown in the table below.

Status	Cause	Corrective Actions
Off	The adapter is not powered or is not transmitting on the network.	<ul style="list-style-type: none"> Program a controller to recognize and transmit I/O to the adapter. Place the controller in RUN mode or apply power. Configure the adapter for the program in the controller.
Steady Green	The adapter is transmitting data on the network.	No action required.

Viewing Adapter Diagnostic Items

If you encounter unexpected communications problems, the adapter’s diagnostic items may help you or Rockwell Automation personnel troubleshoot the problem. Adapter diagnostic items can be viewed using an LCD PowerFlex 7-Class HIM (Diagnostics/Device Items), DriveExplorer software (version 2.01 or higher), or DriveExecutive software (version 1.01 or higher).

Using the HIM to View Adapter Diagnostic Items

Step	Keys	Example Screen
1. Access parameters in the adapter. Refer to Using the PowerFlex 7-Class HIM on page 3-2 .		
2. Press the Up Arrow or Down Arrow to scroll to Diagnostics .	 or 	<div style="border: 1px solid black; padding: 5px;"> Main Menu: Diagnostics Parameter Device Select </div>
3. Press Enter to display the Diagnostics menu in the adapter.		
4. Repeat steps 2 and 3 to enter the Device Items option.		
5. Press the Up Arrow or Down Arrow to scroll through the items.	 or 	<div style="border: 1px solid black; padding: 5px;"> Device Item # 27 Net Packet Rcvd 1022 </div>

Table 8.A Adapter Diagnostic Items

No.	Name	Description
1	Common Logic Cmd	The present value of the Common Logic Command being transmitted to the drive by this adapter.
2	Prod Logic Cmd	The present value of the Product Logic Command being transmitted to the drive by this adapter.
3	Reference	The present value of the Reference being transmitted to the drive by this adapter. Note that a 16-bit value will be sent as the Most Significant Word of the 32-bit field.
4	Common Logic Sts	The present value of the Common Logic Status being received from the drive by this adapter.
5	Prod Logic Sts	The present value of the Product Logic Status being received from the drive by this adapter.
6	Feedback	The present value of the Feedback being received from the drive by this adapter. Note that a 16-bit value will be sent as the Most Significant Word of the 32-bit field.
7	Datalink A1 In	The present value of respective Datalink In being transmitted to the drive by this adapter. (If not using a Datalink, this parameter should have a value of zero. Refer to Chapter 7, Using Datalinks with All Protocols for information about Datalinks.)
8	Datalink A2 In	
9	Datalink B1 In	
10	Datalink B2 In	
11	Datalink C1 In	
12	Datalink C2 In	
13	Datalink D1 In	
14	Datalink D2 In	

Table 8.A Adapter Diagnostic Items (Continued)

No.	Name	Description
15	Datalink A1 Out	The present value of respective Datalink Out being received from the drive by this adapter. (If the drive indicates a 16-bit datalink size, the value appears in the least significant 16 bits of this diagnostic item, and the most significant 16 bits of this diagnostic item are zero. Refer to Chapter 7, Using Datalinks with All Protocols for information about Datalinks.)
16	Datalink A2 Out	
17	Datalink B1 Out	
18	Datalink B2 Out	
19	Datalink C1 Out	
20	Datalink C2 Out	
21	Datalink D1 Out	
22	Datalink D2 Out	
23	Field Flash Cntr	The number of times this device has been flash updated.
24	DPI Rx Errors	The present value of the DPI CAN Receive error counter.
25	DPI Tx Errors	The present value of the DPI CAN Transmit error counter.
26	Net Packet Sent	Number of packets sent by the adapter.
27	Net Packet Rcvd	Number of OK packets received by the adapter.
28	Net Bad Packet	Number of BAD packets received by the adapter.
29	User IN 1	Current value of configurable point User IN 1 (RTU / N2 / P1 FLN).
30	User IN 2	Current value of configurable point User IN 2 (RTU / N2).
31	User IN 3	Current value of configurable point User IN 3 (RTU / N2).
32	User IN 4	Current value of configurable point User IN 4 (RTU / N2).
33	User IN 5	Current value of configurable point User IN 5 (RTU).
34	User IN 6	Current value of configurable point User IN 6 (RTU).
35	User IN 7	Current value of configurable point User IN 7 (RTU).
36	User IN 8	Current value of configurable point User IN 8 (RTU).
37	User OUT 1	Current value of configurable point User OUT 1 (RTU / N2 / P1 FLN).
38	User OUT 2	Current value of configurable point User OUT 2 (RTU / N2).
39	User OUT 3	Current value of configurable point User OUT 3 (RTU).
40	Switch 1	Current value of Rotary Switch 1 (Protocol Select) which can be "1" = RTU, "0" = N2, or "9" = P1.
41	Switch 2	Current value of Rotary Switch 2 (Node Address ones digit).
42	Switch 3	Current value of Rotary Switch 3 (Node Address tens digit).


Viewing and Clearing Events

The adapter has an event queue to record significant events that occur in the operation of the adapter. When such an event occurs, an entry is put into the event queue. You can view the event queue using an LCD PowerFlex 7-Class HIM, DriveExplorer (2.01 or higher) software, DriveExecutive (1.01 or higher) software or other clients using the DPI Fault object.

The event queue can contain up to 32 entries. Eventually the event queue will become full, since its contents are retained through adapter resets. At that point, a new entry replaces the oldest entry. Only an event queue clear operation or adapter power cycle will clear the event queue contents.

Resetting the adapter to defaults has no effect on the event queue.

Using the HIM to View and Clear Events

Step	Keys	Example Screen
Viewing Events		
1. Access parameters in the adapter. Refer to Using the PowerFlex 7-Class HIM on page 3-2 .		
2. Press the Up Arrow or Down Arrow to scroll to Diagnostics .	 or 	
3. Press Enter to display the Diagnostics menu in the adapter.		
4. Repeat steps 2 and 3 to enter the Events option and then View Event Queue option.		
5. Press the Up Arrow or Down Arrow to scroll through the events. The most recent event is Event 1.	 or 	
Clearing Events		
1. Access parameters in the adapter. Refer to Using the PowerFlex 7-Class HIM on page 3-2 .		
2. Press the Up Arrow or Down Arrow to scroll to Diagnostics .	 or 	
3. Press Enter to display the Diagnostics menu in the adapter.		
4. Repeat steps 2 and 3 to enter the Events option and then the Clear Event option or Clr Event Queue option. A message will pop up to confirm that you want to clear the message or queue.		
5. Press Enter to confirm your request. If Clr Event Queue was selected, all event queue entries will then display "No Event."		

Events

Many events in the event queue occur under normal operation. If you encounter unexpected communications problems, the events may help you or Allen-Bradley personnel troubleshoot the problem. The following events may appear in the event queue:

Table 8.B Adapter Events

Code	Event	Description
1	No Event	Empty event queue entry.
2	DPI Bus Off Flt	A bus-off condition was detected on DPI. This event may be caused by loose or broken cables or by noise.
3	Ping Time Flt	A ping message was not received on DPI within the specified time.
4	Port ID Flt	The adapter is not connected to a correct port on a DPI product.
5	Port Change Flt	The DPI port changed after start up.
6	Host Sent Reset	The drive sent a reset event message.
7	EEPROM Sum Flt	The EEPROM in the adapter is corrupt.
8	Online @ 125kbps	The adapter detected that the drive is communicating at 125 kbps.
9	Online @ 500kbps	The adapter detected that the drive is communicating at 500 kbps.
10	Bad Host Flt	The adapter was connected to an incompatible product.
11	Dup Port Flt	Another peripheral with the same port number is already in use.
12	Type 0 Login	The adapter has logged in for Type 0 control.
13	Type 0 Time Flt	The adapter has not received a Type 0 status message within the specified time.
14	DL Login	The adapter has logged into a Datalink.
15	DL Reject Flt	The drive rejected an attempt to log in to a Datalink because the Datalink is not supported or is used by another peripheral.
16	DL Time Flt	The adapter has not received a Datalink message within the specified time.
17	Control Disabled	The adapter has sent a "Soft Control Disable" command to the drive.
18	Control Enabled	The adapter has sent a "Soft Control Enable" command to the drive.
19	Message Timeout	A Client-Server message sent by the adapter was not completed within 1 sec.
20	DPI Fault Msg	The drive has faulted.
21	DPI Fault Clear	The drive issued this because a fault was cleared.
22	Normal Startup	The adapter successfully started up.
23	Flt Cfg Error	The adapter detected a 32-bit fault configuration reference when the drive supports only a 16-bit reference, or detected a 32-bit fault configuration Datalink value when the drive supports only 16-bit Datalinks.
24	Net Comm Flt	The adapter detected a communications fault on the network.
25	Net Detected	The adapter has detected network communication.
26	Net Timeout Flt	The adapter has detected a network timeout. The timeout period is configured in Parameter 11- [Network Timeout].
27	Lang CRC Bad	The CRC of the language text file is incorrect.

Notes:

Specifications

Appendix A presents the specifications for the adapter.

Topic	Page
Communications	A-1
Electrical	A-1
Mechanical	A-1
Environmental	A-1
Regulatory Compliance	A-2

Communications

Network Protocols	Modbus RTU Metasys N2 Siemens Building Technologies P1 FLN
Data Rates - Modbus RTU - Metasys N2 - Siemens Building Technologies P1 FLN	4800, 9600, 19200, or 38400 baud 9600 baud 4800 or 9600 baud
Drive Protocol Data Rates	DPI 125 kbps or 500 kbps

Electrical

Consumption Drive Network	150 mA at 5 VDC supplied by the host (for example, drive) None
---------------------------------	---

Mechanical

Dimensions Height Length Width	19 mm (0.75 inches) 86 mm (3.39 inches) 78.5 mm (3.09 inches)
Weight	85g (3 oz.)

Environmental

Temperature Operating Storage	-10...50°C (14...122°F) -40...85°C (-40...185°F)
Relative Humidity	5...95% non-condensing
Atmosphere	Important: The adapter must not be installed in an area where the ambient atmosphere contains volatile or corrosive gas, vapors or dust. If the adapter is not going to be installed for a period of time, it must be stored in an area where it will not be exposed to a corrosive atmosphere.

Regulatory Compliance

Certification	Specification
UL	UL508C
cUL	CAN / CSA C22.2 No. 14-M91
CE	EN50178 and EN61800-3
CTick	EN61800-3

NOTE: This is a product of category C2 according to IEC 61800-3. In a domestic environment this product may cause radio interference in which case supplementary mitigation measures may be required.

Adapter Parameters

Appendix B provides information about the adapter parameters.

Topic	Page
Parameter List	B-1

Parameter List

Parameter		
No.	Name and Description	Details
01	[DPI Port] Displays the port to which the adapter is connected. This will usually be port 5.	Default: 5 Minimum: 0 Maximum: 7 Type: Read Only
02	[DPI Data Rate] Displays the data rate used by the drive. This data rate is set in the drive and the adapter detects it.	Default: 0 = 125 kbps Values: 0 = 125 kbps 1 = 500 kbps Type: Read Only
03	[Net Addr Cfg] Configures the network node address if the network switches on the adapter are set to "00."	Default: 1 Minimum: 0 Maximum: 247 Type: Read/Write Reset Required: Yes
04	[Net Addr Act] Displays the network address actually used by the adapter.	Default: 1 Minimum: 0 Maximum: 247 Type: Read Only
05	[Net Rate Cfg] Configures the network data rate at which the adapter communicates. The available values for this parameter depend on the network protocol selected. Only valid values for the specified network are displayed.	Default: 1 = 9600 Values: 0 = 4800 1 = 9600 2 = 19200 3 = 38400 Type: Read/Write Reset Required: Yes
06	[Net Rate Act] Displays the network data rate actually used by the adapter.	Default: 1 = 9600 Values: 0 = 4800 1 = 9600 2 = 19200 3 = 38400 Type: Read Only
07	[Net Parity Cfg] Configures the network parity. The available values for this parameter depend on the network protocol selected. Only valid values for the specified network are displayed.	Default: 0 = None Values: 0 = None 1 = Odd 2 = Even Type: Read/Write Reset Required: Yes
08	[Net Parity Act] Displays the actual network parity used by the adapter.	Default: 0 = None Values: 0 = None 1 = Odd 2 = Even Type: Read Only

Parameter		
No.	Name and Description	Details
09	<p>[Stop Bits Act]</p> <p>Displays the actual number of stop bits used by the selected protocol.</p> <p>This value is network-dependent:</p> <ul style="list-style-type: none"> • ModBus RTU Protocol – The number of stop bits used depends on the value set by Parameter 30 - [Stop Bits Cfg]. • Metasys N2 Protocol – Uses only 1 bit, so the adapter shows only this value. • Siemens Building Technologies P1 FLN Protocol – Uses only 1 bit, so the adapter shows only this value. 	<p>Default: 0 = 1-bit</p> <p>Values: 0 = 1-bit 1 = 2-bits</p> <p>Type: Read Only</p>
10	<p>[Net Chksum Type]</p> <p>Displays the type of checksum used by the selected protocol. The value is network dependent:</p> <ul style="list-style-type: none"> • Modbus RTU Protocol – Uses CRC16 (-1) which is Cyclic Redundancy Check with -1 as a seed value. • Metasys N2 Protocol – Uses RLC which is Run Length Checksum. • Siemens Building Technologies P1 FLN – Uses CRC16 (0) which is Cyclic Redundancy Check with 0 as a seed value. 	<p>Default: 0 = CRC16 (0)</p> <p>Values: 0 = CRC16 (0) 1 = RLC 2 = CRC16 (-1)</p> <p>Type: Read Only</p>
11	<p>[Network Timeout]</p> <p>Configures the time in seconds to be used to detect network communication loss.</p>	<p>Default: 10 seconds</p> <p>Minimum: 0 seconds</p> <p>Maximum: 180 seconds</p> <p>Type: Read/Write</p> <p>Reset Required: No</p>
<p> ATTENTION: Risk of injury or equipment damage exists. Parameter 11 - [Network Timeout] lets you determine how long it will take your adapter to detect network communication losses. By default, this parameter sets the timeout to ten seconds. You can set it so that the duration is shorter, longer, or disabled. Take precautions to ensure that the setting does not create a risk of injury or equipment damage. When commissioning the drive, verify that your system responds correctly to various situations (for example, a disconnected cable).</p>		
12	<p>[Ref/Fdbk Size]</p> <p>Displays the size of the Reference/Feedback. The drive determines the size of the Reference/Feedback.</p>	<p>Default: 0 = 16-bit</p> <p>Values: 0 = 16-bit 1 = 32-bit</p> <p>Type: Read Only</p>
13	<p>[Datalink Size]</p> <p>Displays the size of each Datalink word. The drive determines the size of Datalinks.</p>	<p>Default: 0 = 16-bit</p> <p>Values: 0 = 16-bit 1 = 32-bit</p> <p>Type: Read Only</p>
14	<p>[Reset Module]</p> <p>No action if set to "0" (Ready). Resets the adapter if set to "1" (Reset Module). Restores the adapter to its factory default settings if set to "2" (Set Defaults). This parameter is a command. It will be reset to "0" (Ready) after the command has been performed.</p>	<p>Default: 0 = Ready</p> <p>Values: 0 = Ready 1 = Reset Module 2 = Set Defaults</p> <p>Type: Read/Write</p> <p>Reset Required: No</p>
<p> ATTENTION: Risk of injury or equipment damage exists. If the adapter is transmitting I/O that controls the drive, the drive may fault when you reset the adapter. Determine how your drive will respond before resetting a connected adapter.</p>		

Parameter																														
No.	Name and Description	Details																												
15	<p>[Comm Fit Action]</p> <p>Sets the action that the adapter will take if it detects a network failure because it has not communicated with its master within the interval specified in Parameter 11 - [Network Timeout]. This action takes effect only if I/O that controls the drive is transmitted through the adapter.</p>	<p>Default: 0 = Fault</p> <p>Values: 0 = Fault 1 = Stop 2 = Zero Data 3 = Hold Last 4 = Send Fit Cfg</p> <p>Type: Read/Write</p> <p>Reset Required: No</p>																												
	<p> ATTENTION: Risk of injury or equipment damage exists. Parameter 15 - [Comm Fit Action] lets you determine the action of the adapter and connected drive if I/O communications are disrupted. By default, this parameter faults the drive. You can set this parameter so that the drive continues to run. Precautions should be taken to ensure that the setting of this parameter does not create a risk of injury or equipment damage. When commissioning the drive, verify that your system responds correctly to various situations (for example, a disconnected cable).</p>																													
16	<p>[DPI I/O Cfg]</p> <p>Sets the I/O that is transferred through the adapter.</p>	<p>Default: xxx0 0001</p> <p>Bit Values: 0 = I/O disabled 1 = I/O enabled</p> <p>Type: Read/Write</p> <p>Reset Required: Yes</p>	<table border="1"> <thead> <tr> <th>Bit Definition</th> <th>Not Used</th> <th>Not Used</th> <th>Not Used</th> <th>Datalink D*</th> <th>Datalink C*</th> <th>Datalink B</th> <th>Datalink A</th> <th>Cmd/Ref</th> </tr> </thead> <tbody> <tr> <td>Default</td> <td>x</td> <td>x</td> <td>x</td> <td>0</td> <td>0</td> <td>0</td> <td>0</td> <td>1</td> </tr> <tr> <td>Bit</td> <td>7</td> <td>6</td> <td>5</td> <td>4</td> <td>3</td> <td>2</td> <td>1</td> <td>0</td> </tr> </tbody> </table> <p>*Not used with Metasys N2.</p>	Bit Definition	Not Used	Not Used	Not Used	Datalink D*	Datalink C*	Datalink B	Datalink A	Cmd/Ref	Default	x	x	x	0	0	0	0	1	Bit	7	6	5	4	3	2	1	0
Bit Definition	Not Used	Not Used	Not Used	Datalink D*	Datalink C*	Datalink B	Datalink A	Cmd/Ref																						
Default	x	x	x	0	0	0	0	1																						
Bit	7	6	5	4	3	2	1	0																						
17	<p>[DPI I/O Act]</p> <p>Displays the I/O that the adapter is actively transmitting. The value of this parameter will usually be equal to the value of Parameter 16 - [DPI I/O Cfg].</p>	<p>Default: xxx0 0001</p> <p>Bit Values: 0 = I/O disabled 1 = I/O enabled</p> <p>Type: Read Only</p>	<table border="1"> <thead> <tr> <th>Bit Definition</th> <th>Not Used</th> <th>Not Used</th> <th>Not Used</th> <th>Datalink D*</th> <th>Datalink C*</th> <th>Datalink B</th> <th>Datalink A</th> <th>Cmd/Ref</th> </tr> </thead> <tbody> <tr> <td>Default</td> <td>x</td> <td>x</td> <td>x</td> <td>0</td> <td>0</td> <td>0</td> <td>0</td> <td>1</td> </tr> <tr> <td>Bit</td> <td>7</td> <td>6</td> <td>5</td> <td>4</td> <td>3</td> <td>2</td> <td>1</td> <td>0</td> </tr> </tbody> </table> <p>*Not used with Metasys N2.</p>	Bit Definition	Not Used	Not Used	Not Used	Datalink D*	Datalink C*	Datalink B	Datalink A	Cmd/Ref	Default	x	x	x	0	0	0	0	1	Bit	7	6	5	4	3	2	1	0
Bit Definition	Not Used	Not Used	Not Used	Datalink D*	Datalink C*	Datalink B	Datalink A	Cmd/Ref																						
Default	x	x	x	0	0	0	0	1																						
Bit	7	6	5	4	3	2	1	0																						
18	<p>[Fit Cfg Logic]</p> <p>Sets the Logic Command data that is sent to the drive if Parameter 15 - [Comm Fit Action] is set to "4" (Send Fit Cfg) and the adapter times out.</p> <p>The bit definitions will depend on the product to which the adapter is connected. See Appendix C or the documentation for the drive being used.</p>	<p>Default: 0000 0000 0000 0000</p> <p>Minimum: 0000 0000 0000 0000</p> <p>Maximum: 1111 1111 1111 1111</p> <p>Type: Read/Write</p> <p>Reset Required: No</p>																												
19	<p>[Fit Cfg Ref]</p> <p>Sets the Reference data that is sent to the drive if Parameter 15 - [Comm Fit Action] is set to "4" (Send Fit Cfg) and the adapter times out.</p>	<p>Default: 0</p> <p>Minimum: 0</p> <p>Maximum: 4294967295</p> <p>Type: Read/Write</p> <p>Reset Required: No</p> <p>Important: If the drive uses a 16-bit Reference, the most significant word of this value must be set to zero (0) or a fault will occur.</p>																												

Parameter		
No.	Name and Description	Details
20	[Fit Cfg A1 In]	Default: 0
21	[Fit Cfg A2 In]	Default: 0
22	[Fit Cfg B1 In]	Default: 0
23	[Fit Cfg B2 In]	Default: 0
24	[Fit Cfg C1 In]	Default: 0
25	[Fit Cfg C2 In]	Default: 0
26	[Fit Cfg D1 In]	Default: 0
27	[Fit Cfg D2 In]	Default: 0
	<p>Sets the data that is sent to the Datalink in the drive if Parameter 15 - [Comm Flt Action] is set to "4" (Send Flt Cfg) and the adapter times out.</p>	<p>Minimum: 0 Maximum: 4294967295 Type: Read/Write Reset Required: No</p> <p>Important: If the drive uses 16-bit Datalinks, the most significant word of this value must be set to zero (0) or a fault will occur.</p>
28	[Clear Counters]	Default: 0 = Ready
	Clears the network diagnostic counters.	<p>Values: 0 = Ready 1 = Clear Type: Read/Write Reset Required: No</p>
29	[N2 Ref Scale]	Default: 32767
	<p>Only used if Metasys N2 protocol is selected. Determines the engineering unit sent over DPI for the Reference when 100% is set for AO#2.</p>	<p>Minimum: 0 Maximum: 4294967295 Type: Read/Write Reset Required: No</p>
30	[Stop Bits Cfg]	Default: 0 = 1 bit
	<p>Sets the number of stop bits used by the adapter when the network protocol switch is set to "Modbus RTU." When any other protocol is selected, this parameter setting has no effect.</p>	<p>Values: 0 = 1 bit 1 = 2 bits Type: Read/Write Reset Required: Yes</p>
31	[RTU Ref Adjust]	Default: 100.0%
	<p>Sets the percent scale factor for the Reference from the network when the network protocol switch is set to "Modbus RTU," and broadcast messages (Modbus address "0") are sent. This lets the drive's Reference either match the broadcast message Reference (=100%), scale below it (<100%), or scale above it (>100%). When any other protocol is selected, this parameter setting has no effect.</p>	<p>Minimum: 0.0% Maximum: 200.0% Type: Read/Write Reset Required: No</p>
	 <p>ATTENTION: To guard against equipment damage and/or personal injury, note that changes to Parameter 31 - [RTU Ref Adjust] take effect immediately. A drive receiving a broadcast message Reference from the adapter will receive the newly scaled Reference, resulting in a change of speed.</p>	
32	[RTU Param Mode]	Default: 0 = 16-bit Mode
	Sets the mode in which the adapter operates.	<p>Values: 0 = 16-bit Mode 1 = 32-bit Mode Type: Read/Write Reset Required: Yes</p>

Logic Command/Status Words

Appendix D presents the definitions of the Logic Command and Logic Status words that are used for some products that can be connected to the adapter. If you do not see the Logic Command/Logic Status for the product that you are using, refer to your product's documentation.

PowerFlex 7-Class Drives (except PowerFlex 700S) Logic Command Word

Logic Bits																Command	Description
15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0		
															x	Stop ⁽¹⁾	0 = Not Stop 1 = Stop
															x	Start ⁽¹⁾⁽²⁾	0 = Not Start 1 = Start
														x		Jog	0 = Not Jog 1 = Jog
												x				Clear Faults	0 = Not Clear Faults 1 = Clear Faults
										x	x					Direction	00 = No Command 01 = Forward Command 10 = Reverse Command 11 = Hold Direction Control
									x							Local Control	0 = No Local Control 1 = Local Control
								x								MOP Increment	0 = Not Increment 1 = Increment
						x	x									Accel Rate	00 = No Command 01 = Accel Rate 1 Command 10 = Accel Rate 2 Command 11 = Hold Accel Rate
				x	x											Decel Rate	00 = No Command 01 = Decel Rate 1 Command 10 = Decel Rate 2 Command 11 = Hold Decel Rate
	x	x	x													Reference Select ⁽³⁾	000 = No Command 001 = Ref. 1 (Ref A Select) 010 = Ref. 2 (Ref B Select) 011 = Ref. 3 (Preset 3) 100 = Ref. 4 (Preset 4) 101 = Ref. 5 (Preset 5) 110 = Ref. 6 (Preset 6) 111 = Ref. 7 (Preset 7)
x																MOP Decrement	0 = Not Decrement 1 = Decrement

⁽¹⁾ A "0 = Not Stop" condition (logic 0) must first be present before a "1 = Start" condition will start the drive. The Start command acts as a momentary Start command. A "1" will start the drive, but returning to "0" will not stop the drive.

⁽²⁾ This Start will not function if a digital input (parameters 361-366) is programmed for 2-Wire Control (option 7, 8 or 9).

⁽³⁾ This Reference Select will not function if a digital input (parameters 361-366) is programmed for "Speed Sel 1, 2 or 3" (option 15, 16 or 17). Note that Reference Select is "Exclusive Ownership" – see drive User Manual for more information.

Logic Status Word

Logic Bits																Status	Description
15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0		
															x	Ready	0 = Not Ready 1 = Ready
															x	Active	0 = Not Active 1 = Active
														x		Command Direction	0 = Reverse 1 = Forward
												x				Actual Direction	0 = Reverse 1 = Forward
											x					Accel	0 = Not Accelerating 1 = Accelerating
										x						Decel	0 = Not Decelerating 1 = Decelerating
									x							Alarm	0 = No Alarm 1 = Alarm
								x								Fault	0 = No Fault 1 = Fault
							x									At Speed	0 = Not At Reference 1 = At Reference
				x	x	x										Local Control ⁽¹⁾	000 = Port 0 (TB) 001 = Port 1 010 = Port 2 011 = Port 3 100 = Port 4 101 = Port 5 110 = Port 6 111 = No Local
x	x	x	x													Reference	0000 = Ref A Auto 0001 = Ref B Auto 0010 = Preset 2 Auto 0011 = Preset 3 Auto 0100 = Preset 4 Auto 0101 = Preset 5 Auto 0110 = Preset 6 Auto 0111 = Preset 7 Auto 1000 = Term Blk Manual 1001 = DPI 1 Manual 1010 = DPI 2 Manual 1011 = DPI 3 Manual 1100 = DPI 4 Manual 1101 = DPI 5 Manual 1110 = DPI 6 Manual 1111 = Jog Ref

(1) See "Owners" in drive User Manual for further information.

PowerFlex 700S Drives

Logic Command Word (Phase II Control)

Logic Bits																Command	Description																																								
15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0																																										
															x	Normal Stop	0 = Not Normal Stop 1 = Normal Stop																																								
															x	Start ⁽¹⁾	0 = Not Start 1 = Start																																								
														x		Jog 1	0 = Not Jog using [Jog Speed 1] 1 = Jog using [Jog Speed 1]																																								
													x			Clear Fault ⁽²⁾	0 = Not Clear Fault 1 = Clear Fault																																								
										x	x					Unipolar Direction	00 = No Command 01 = Forward Command 10 = Reverse Command 11 = Hold Direction Control																																								
									x							Reserved																																									
								x								Jog 2	0 = Not Jog using [Jog Speed 2] 1 = Jog using [Jog Speed 2]																																								
							x									Current Limit Stop	0 = Not Current Limit Stop 1 = Current Limit Stop																																								
						x										Coast Stop	0 = Not Coast to Stop 1 = Coast to Stop																																								
					x											Reserved																																									
				x												Reserved																																									
			x													Spd Ref Sel0	<table border="1"> <thead> <tr> <th colspan="3">Bits</th> <th></th> </tr> <tr> <th>14</th><th>13</th><th>12</th><th></th> </tr> </thead> <tbody> <tr> <td>0</td><td>0</td><td>0</td><td>= Spd Ref A</td> </tr> <tr> <td>0</td><td>0</td><td>1</td><td>= Spd Ref B</td> </tr> <tr> <td>0</td><td>1</td><td>0</td><td>= Preset 2</td> </tr> <tr> <td>0</td><td>1</td><td>1</td><td>= Ref. 3 (Preset 3)</td> </tr> <tr> <td>1</td><td>0</td><td>0</td><td>= Ref. 4 (Preset 4)</td> </tr> <tr> <td>1</td><td>0</td><td>1</td><td>= Ref. 5 (Preset 5)</td> </tr> <tr> <td>1</td><td>1</td><td>0</td><td>= Ref. 6 (Preset 6)</td> </tr> <tr> <td>1</td><td>1</td><td>1</td><td>= Ref. 7 (Preset 7)</td> </tr> </tbody> </table>	Bits				14	13	12		0	0	0	= Spd Ref A	0	0	1	= Spd Ref B	0	1	0	= Preset 2	0	1	1	= Ref. 3 (Preset 3)	1	0	0	= Ref. 4 (Preset 4)	1	0	1	= Ref. 5 (Preset 5)	1	1	0	= Ref. 6 (Preset 6)	1	1	1	= Ref. 7 (Preset 7)
Bits																																																									
14	13	12																																																							
0	0	0	= Spd Ref A																																																						
0	0	1	= Spd Ref B																																																						
0	1	0	= Preset 2																																																						
0	1	1	= Ref. 3 (Preset 3)																																																						
1	0	0	= Ref. 4 (Preset 4)																																																						
1	0	1	= Ref. 5 (Preset 5)																																																						
1	1	0	= Ref. 6 (Preset 6)																																																						
1	1	1	= Ref. 7 (Preset 7)																																																						
		x														Spd Ref Sel1																																									
	x															Spd Ref Sel2																																									
x																Reserved																																									

⁽¹⁾ A Not Stop condition (logic bit 0 = 0, logic bit 8 = 0, and logic bit 9 = 0) must first be present before a 1 = Start condition will start the drive.

⁽²⁾ To perform this command, the value must switch from “0” to “1.”

Logic Status Word (Phase II Control)

Logic Bits																Status	Description
15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0		
															x	Active	0 = Not Active 1 = Active
															x	Running	0 = Not Running 1 = Running
														x		Command Direction	0 = Reverse 1 = Forward
													x			Actual Direction	0 = Reverse 1 = Forward
											x					Accel	0 = Not Accelerating 1 = Accelerating
										x						Decel	0 = Not Decelerating 1 = Decelerating
									x							Jogging	0 = Not Jogging 1 = Jogging
								x								Fault	0 = No Fault 1 = Fault
							x									Alarm	0 = No Alarm 1 = Alarm
						x										Flash Mode	0 = Not in Flash Mode 1 = In Flash Mode
					x											Run Ready	0 = Not Ready to Run 1 = Ready to Run
				x												At Limit ⁽¹⁾	0 = Not At Limit 1 = At Limit
			x													Tach Loss Sw	0 = Not Tach Loss Sw 1 = Tach Loss Sw
		x														At Zero Spd	0 = Not At Zero Speed 1 = At Zero Speed
	x															At Setpt Spd	0 = Not At Setpoint Speed 1 = At Setpoint Speed
x																Enable	0 = Not Enabled 1 = Enabled

⁽¹⁾ See Parameter 304 - [Limit Status] in the PowerFlex 700S drive User Manual for a description of the limit status conditions.

A Adapter

Devices such as drives, controllers, and computers usually require an adapter to provide a communication interface between them and a network. An adapter reads data on the network and transmits it to the connected device. It also reads data in the device and transmits it to the network.

The 20-COMM-H RS-485 HVAC adapter connects a PowerFlex 7-Class drive to the network. Adapters are sometimes also called “cards,” “embedded communication options,” “gateways,” “modules,” and “peripherals.”

B Bus Off

A condition that occurs when an abnormal rate of errors is detected in a device. The bus off device cannot receive or transmit messages on the network. This condition is often caused by corruption of the network data signals due to noise or data rate mismatch.

C ControlFLASH

An Allen-Bradley software tool that lets users electronically update firmware on printed circuit boards. The tool takes advantage of the growing use of flash memory (electronic erasable chips) across industrial control products.

Controller

A controller, also called programmable logic controller, is a solid-state control system that has a user-programmable memory for storage of instructions to implement specific functions such as I/O control, logic, timing, counting, report generation, communication, arithmetic, and data file manipulation. A controller consists of a central processor, input/output interface, and memory. See also Scanner.

D Data Rate

The speed at which data is transferred on the network. Each device on a network must be set to the same data rate.

Datalinks

A Datalink is a type of pointer used by some PowerFlex drives to transfer data to and from the controller. Datalinks allow specified parameter value(s) to be accessed or changed without using explicit messages. When enabled, each Datalink consumes either four bytes or eight bytes in both the input and output image table of the controller. The drive determines the size of Datalinks.

DPI (Drive Peripheral Interface)

A second generation peripheral communication interface used by various Allen-Bradley drives and power products, such as PowerFlex 7-Class drives.

DPI Peripheral

A device that provides an interface between DPI and a network or user. Peripheral devices are also referred to as “adapters” or “modules.” The 20-COMM-H adapter and PowerFlex 7-Class HIMs (20-HIM-xxx) are examples of DPI peripherals.

DPI Product

A device that uses the DPI communications interface to communicate with one or more peripheral devices. For example, a motor drive such as a PowerFlex 7-Class drive is a DPI product. In this manual, a DPI product is also referred to as “drive” or “host.”

DriveExplorer Software

A tool for monitoring and configuring Allen-Bradley products and adapters. It can be run on computers running various Microsoft Windows operating systems. DriveExplorer (version 3.xx or higher) can be used to configure this adapter and PowerFlex drive. Information about DriveExplorer software and a free lite version can be accessed at <http://www.ab.com/drives/driveexplorer>.

DriveTools SP Software

A software suite designed for running on various Microsoft Windows operating systems. This software suite provides a family of tools, including DriveExecutive, that you can use to program, monitor, control, troubleshoot, and maintain Allen-Bradley products. DriveTools SP can be used with PowerFlex drives. Information about DriveTools SP can be accessed at <http://www.ab.com/drives/drivetools>.

F Fault Action

A fault action determines how the adapter and connected drive act when a communications fault (for example, a cable is disconnected) occurs.

Fault Configuration

When communications are disrupted (for example, a cable is disconnected), the adapter and PowerFlex drive can respond with a user-defined fault configuration. The user sets the data that is sent to the drive using specific fault configuration parameters in the adapter. When a fault action parameter is set to use the fault configuration data and a fault occurs, the data from these parameters is sent as the Logic Command, Reference, and/or Datalink(s).

Flash Update

The process of updating firmware in a device. The adapter can be flash updated using various Allen-Bradley software tools. Refer to [Flash Updating the Adapter on page 3-10](#) for more information.

H HIM (Human Interface Module)

A device that can be used to configure and control a drive. PowerFlex 7-Class HIMs (20-HIM-xxx) can be used to configure PowerFlex 7-Class drives and their connected peripherals.

Hold Last

When communication is disrupted (for example, a cable is disconnected), the adapter and PowerFlex drive can respond by holding last. Hold last results in the drive receiving the last data received via the network connection before the disruption. If the drive was running and using the Reference from the adapter, it will continue to run at the same Reference.

I I/O Data

I/O data, sometimes called “implicit messages” or “input/output,” is time-critical data such as a Logic Command and Reference. The terms “input” and “output” are defined from the controller’s point of view. Output is produced by the controller and consumed by the adapter. Input is produced by the adapter and consumed by the controller.

L Logic Command/Logic Status

The Logic Command is used to control the PowerFlex 7-Class drive (for example, start, stop, direction). It consists of one 16-bit word of output to the adapter from the network. The definitions of the bits in this word depend on the drive, and are shown in [Appendix C](#).

The Logic Status is used to monitor the PowerFlex 7-Class drive (for example, operating state, motor direction). It consists of one 16-bit word of input from the adapter to the network. The definitions of the bits in this word depend on the drive, and are shown in [Appendix C](#).

N Node Address

Each device on a network must have a unique node address to identify it. On Modbus RTU, Metasys N2, and Siemens Building Technologies P1 FLN networks, devices can have node addresses between 1 and 255 if the network is set up to accommodate that number of devices.

NVS (Non-Volatile Storage)

NVS is the permanent memory of a device. Devices such as the adapter and drive store parameters and other information in NVS so that they are not lost when the device loses power. NVS is sometimes called “EEPROM.”

P Parity Check

When the adapter uses a parity check, a non-data bit is added to each binary word that it sends and receives. Devices on the network verify the data integrity of the transmitted data by checking that the sum of the number of ones in a word is always even or odd.

Ping

A message that is sent by a DPI product to its peripheral devices. They use the ping to gather data about the product, including whether it can receive messages and whether they can log in for control.

PowerFlex 7-Class (Architecture Class) Drives

The Allen-Bradley PowerFlex 7-Class family of drives supports DPI and includes the PowerFlex 70, PowerFlex 700, PowerFlex 700H, PowerFlex 700S, PowerFlex 700L, and PowerFlex 7000. These drives can be used for applications ranging from 0.37...3000 kW (0.5...4000 HP).

R Reference/Feedback

The Reference is used to send a setpoint (for example, speed, frequency, torque) to the drive. It consists of one word of output to the adapter from the network. The size of the word (either a 16-bit word or 32-bit word) is determined by the drive.

Feedback is used to monitor the speed of the drive. It consists of one word of input from the adapter to the network. The size of the word (either a 16-bit word or 32-bit word) is determined by the drive.

S Scanner

A scanner is a separate module (of a multi-module controller) or a built-in component (of a single-module controller) that provides communication with adapters connected to a network. See also Controller.

Status Indicators

Status indicators are LEDs that are used to report the status of the adapter, network, and drive. They are on the adapter and can be viewed on the front cover of the drive when the drive is powered.

T Type 0/Type 1/Type 2 Control

When transmitting I/O, the adapter can use different types of messages for control. The Type 0, Type 1, and Type 2 events help Allen-Bradley personnel identify the type of messages that an adapter is using.

Z Zero Data

When communications are disrupted (for example, a cable is disconnected), the adapter and drive can respond with zero data. Zero data results in the drive receiving zero as values for Logic Command, Reference, and Datalink data. If the drive was running and using the Reference from the adapter, it will stay running but at zero Reference.

A

adapter

- applying power, **2-7**
- commissioning, **2-1**
- compatible products, **1-2**
- components, **1-1**
- configuration tools, **3-1**
- configuring I/O for, **3-5**
- connecting to a drive, **2-3**
- connecting to the network, **2-6**
- definition, **G-1**
- features, **1-2**
- flash updating, **3-10**
- grounding, **2-5**
- installation, **2-1 to 2-8**
- mounting on the drive, **2-5**
- parameters, **B-1 to B-4**
- resetting, **3-8**
- selecting operating mode, **B-4**
- specifications, **A-1**
- viewing its status, **3-9**

applying power to the adapter, **2-7**

attentions, **1-3**

B

baud rate, *see data rate*

bit definitions of Logic Command/Status word for

- PowerFlex 70/700/700H drives, **C-1**
- PowerFlex 700S drives, **C-3**

bus off, **G-1**

C

cables

- DPI Internal Interface, **2-3, 2-4**
- network, **2-6**

Clear Counters parameter, **B-4**

Comm Flt Action parameter, **B-3**

commissioning the adapter, **2-1**

communications module, *see adapter*

compatible products, **1-2**

components of the adapter, **1-1**

configuration tools, **3-1**

connecting adapter to the

- network, **2-6**

connecting adapter to the drive, **2-3**

connector on adapter, **1-1**

ControlFLASH, **G-1**

controller, **G-1**

D

data rate

- definition, **G-1**
- setting, **3-3**

data transfers

- advanced (all protocols), **7-1 to 7-6**
- Metasys N2, **5-1 to 5-9**
- Modbus RTU, **4-1 to 4-13**
- Siemens Building Technologies P1 FLN, **6-1 to 6-10**

Datalink Size parameter, **B-2**

Datalinks

- definition, **G-1**
- Metasys N2, **7-4**
- Modbus RTU, **7-3 to 7-4**
- Siemens Building Technologies P1 FLN, **7-5 to 7-6**
- using with all protocols, **7-1 to 7-6**

diagnostic items, **8-4**

dimensions, **A-1**

DPI

- connector on adapter, **1-1**
- data rates, **A-1**
- definition, **G-1**
- Internal Interface cable, **2-3, 2-4**
- peripheral, **G-2**
- products, **1-2, G-2**

DPI Data Rate parameter, **B-1**

DPI I/O Act parameter, **B-3**

DPI I/O Cfg parameter, **B-3**

DPI Port parameter, **B-1**

DriveExecutive software

- adapter configuration tool, **3-1**
- definition/web site, **G-2**

DriveExplorer software

- adapter configuration tool, **3-1**
- definition/web site, **G-2**
- free lite version, **G-2**

drives, *see PowerFlex drives*

DriveTools SP software, **G-2**

E

EEPROM, *see Non-Volatile Storage (NVS)*

environmental specifications, **A-1**
equipment required, **1-3**
events
clearing/viewing, **8-6**
list of, **8-7**

F

fault action
configuring the adapter for, **3-7**
definition, **G-2**
fault configuration
configuring the adapter for, **3-7**
definition, **G-2**
faults, *see events*
features, **1-2**
firmware release, **P-2**
flash update
definition, **G-2**
guidelines, **3-10**
Flt Cfg A1-D2 In parameters, **B-4**
Flt Cfg Logic parameter, **B-3**
Flt Cfg Ref parameter, **B-3**

G

grounding the adapter, **2-5**

H

HIM (Human Interface Module)
accessing parameters with, **3-2**
definition, **G-3**
LCD model, **3-2**
LED model, **3-2**
hold last
configuring the adapter for, **3-7**
definition, **G-3**

I

I/O
configuring the adapter for, **3-5**
definition, **G-3**
installation
applying power to the adapter, **2-7**
connecting to the drive, **2-3**
connecting to the network, **2-6**
preparing for, **2-1**

Internal Interface cables
connecting to the adapter, **2-4**
connecting to the drive, **2-4**
illustration, **2-4**

L

LCD HIM, **3-2**
LED HIM, **3-2**
LEDs, *see status indicators*
Logic Command/Status
bit definitions for
PowerFlex 70/700/700H drives, **C-1**
PowerFlex 700S drives, **C-3**
definition, **G-3**
on Metasys N2, **5-3 to 5-6**
on Modbus RTU, **4-7 to 4-8**
on Siemens Building Technologies P1 FLN,
6-5 to 6-9

M

manual
conventions, **P-2**
related documentation, **P-1**
web site, **P-1**
mechanical dimensions, **A-1**
Metasys N2
data transfers, **5-1 to 5-9**
Datalinks, **7-4**
point map, **5-3 to 5-6**
selecting with a switch, **2-2**
MOD status indicator
locating, **1-6**
troubleshooting with, **8-2**
Modbus RTU
accessing drive parameters, **4-9**
broadcast messages, **4-12**
data transfers, **4-1 to 4-13**
Datalinks, **7-3 to 7-4**
point map, **4-4 to 4-8**
selecting with a switch, **2-2**
mounting the adapter, **2-5**

N

N2 Ref Scale parameter, **B-4**
NET A status indicator
locating, **1-6**
troubleshooting with, **8-3**

- Net Addr Act parameter, **B-1**
 - Net Addr Cfg parameter, **B-1**
 - NET B status indicator
 - locating, **1-6**
 - troubleshooting with, **8-3**
 - Net Chksum Type parameter, **B-2**
 - Net Parity Act parameter, **B-1**
 - Net Parity Cfg parameter, **B-1**
 - Net Rate Act parameter, **B-1**
 - Net Rate Cfg parameter, **B-1**
 - network
 - cable, **2-6**
 - data rates, **A-1**
 - protocols
 - Metasys N2, **5-1**
 - Modbus RTU, **4-1**
 - selecting with a switch, **2-2**
 - Siemens Building Technologies P1 FLN, **6-1**
 - Network Timeout parameter, **B-2**
 - node address
 - definition, **G-3**
 - setting with a parameter, **3-3**
 - setting with switches, **2-2**
 - Non-Volatile Storage (NVS)
 - definition, **G-3**
 - in adapter, **3-1**
- O**
- operating mode selection for adapter, **B-4**
- P**
- parameters
 - accessing, **3-1**
 - convention, **P-2**
 - list of, **B-1 to B-4**
 - restoring to factory-default settings, **3-8**
 - parity check, **G-3**
 - parity setting, **3-4**
 - ping, **G-4**
 - point map
 - Metasys N2, **5-3 to 5-6**
 - Modbus RTU, **4-4 to 4-8**
 - Siemens Building Technologies P1 FLN, **6-3**
 - PORT status indicator
 - locating, **1-6**
 - troubleshooting with, **8-2**
 - power consumption, **A-1**
 - PowerFlex drives
 - compatible with adapter, **1-2**
 - definition, **G-4**
 - HIM, **3-2**
 - preparing for an installation, **2-1**
 - processor, *see controller*
 - programmable logic controller, *see controller*
- Q**
- quick start, **1-5**
- R**
- Ref/Fdbk Size parameter, **B-2**
 - Reference/Feedback, **G-4**
 - regulatory compliance, **A-2**
 - related documentation, **P-1**
 - Reset Module parameter, **B-2**
 - ribbon cable, *see Internal Interface cable*
 - RTU Param Mode parameter, **B-4**
 - RTU Ref Adjust parameter, **B-4**
- S**
- safety precautions, **1-3**
 - scanner, **G-4**
 - selecting adapter operating mode, **B-4**
 - Siemens Building Technologies P1 FLN
 - data transfers, **6-1 to 6-10**
 - Datalinks, **7-5 to 7-6**
 - selecting with a switch, **2-2**
 - specifications for the adapter, **A-1**
 - status indicators
 - definition, **G-4**
 - locating, **1-6**
 - MOD, **1-6, 8-2**
 - NET A, **1-6, 8-3**
 - NET B, **1-6, 8-3**
 - normal operation, **2-7**
 - PORT, **1-6, 8-2**
 - troubleshooting with, **8-2 to 8-3**
 - understanding, **8-1**
 - Stop Bits Act parameter, **B-2**
 - Stop Bits Cfg parameter, **B-4**
 - switches
 - network protocol, **2-2**
 - node address, **2-2**

T

technical support, **P-2**
tools required, **1-3**
troubleshooting, **8-1 to 8-7**
Type 0/Type 1/Type 2 control, **G-4**

U

update, *see flash update*

W

web site
 DriveExecutive software, **G-2**
 DriveExplorer software, **G-2**
 DriveTools SP software, **G-2**
 manuals, **P-1**
wiring, *see cables*

Z

zero data
 configuring the adapter for, **3-7**
 definition, **G-4**



U.S. Allen-Bradley Drives Technical Support - Tel: (1) 262.512.8176, Fax: (1) 262.512.2222, Email: support@drives.ra.rockwell.com, Online: www.ab.com/support/abdrives

www.rockwellautomation.com

Power, Control and Information Solutions Headquarters

Americas: Rockwell Automation, 1201 South Second Street, Milwaukee, WI 53204 USA, Tel: (1) 414.382.2000, Fax: (1) 414.382.4444

Europe/Middle East/Africa: Rockwell Automation, Vorstlaan/Boulevard du Souverain 36, 1170 Brussels, Belgium, Tel: (32) 2 663 0600, Fax: (32) 2 663 0640

Asia Pacific: Rockwell Automation, Level 14, Core F Cyberport 3, 100 Cyberport Road, Hong Kong, Tel: (852) 2887 4788, Fax: (852) 2508 1846

Publication 20COMM-UM009D-EN-P – September, 2009

Supersedes 20COMM-UM009C-EN-P – March, 2004

Copyright © 2009 Rockwell Automation, Inc. All rights reserved. Printed in USA.